

Onan

Genset *Parts Catalog*

**KV
KVC
KVD**



Printed in U.S.A.

1/05 981-0238G
(KV Spec A-L) (KVC Spec A-C)
(KVD Spec A-B)
Replaces 5-02 (KV Spec A-K
KVC Spec A-C and KVD)

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameplate information in the spaces below.

MODEL AND SPEC NO.

SERIAL NO.

DIGITAL CONTROL SOFTWARE VERSION
AND DATE (IF APPLICABLE)

SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of equipment and replacement of parts. Please read and observe.



This symbol warns of immediate hazards which will result in severe personal injury or death.



This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



This symbol refers to a hazard or unsafe practice which can result in severe personal injury or product or property damage.

PRODUCT SAFETY PRECAUTIONS



Service and repair of Onan equipment must be performed by trained, experienced personnel only. Improper service or repair may result in property damage, severe personal injury or death. Do not use this catalog as a guide to servicing your equipment. Read and follow the IMPORTANT SAFETY INSTRUCTIONS in the Service Manual appropriate for the equipment you are working on.



Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.



Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!



Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives or using solvents take all necessary precautions not to ingest, breathe the fumes or contact the liquids. Use adequate ventilation and wear protective gloves, masks and protective clothing!

Introduction

This manual applies to the standard Recreational Vehicle Generator Sets as listed in the Generator Set Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Parts illustrations are typical. Using the model and specification number from your generator set nameplate, select parts that apply to your set. Right and left sides are determined by facing the engine end (front) of the set.

Generator Set Data Table				
MODEL AND SPECIFICATION	VOLTS	HERTZ	FUEL	WIRING DIAGRAM
1.7KV-FU/29236A,B	240	50	Gasoline	610-0376
2.0KV-FR/26119B	230	50	LP	610-0376
2.0KV-FR/26119,C,D,E	230	50	LP	610-0383
2.0KV-FR/26119F,G,H,J	230	50	LP	610-0389
2.0KV-FR/26119K,L	230	50	LP	610-0389
2.0KV-FR/33742B	220	50	Gasoline	610-0376
2.0KV-FR/33742C,D,E	220	50	Gasoline	610-0383
2.0KV-FR/33742F,G	220	50	Gasoline	610-0389
2.0KV-FR/37544A,B	110/220	50	Gasoline	610-0380
2.0KV-FR/51844C,E	220	50	Gasoline	610-0384
2.0KV-FR/51844F,G	220	50	Gasoline	610-0390
2.2KV-FA/26100A,B	120	60	Gasoline	610-0375
2.3KV-FR/33742F,G,J,K	220	50	Gasoline	610-0389
2.3KV-FR/51844F,G,J,K	220	50	Gasoline	610-0390
2.5KV-FR/11540F,G,H,J	100	60	LP	610-0394
2.5KV-FR/11540K,L	100	60	LP	610-0394
2.5KV-FA/26120B	120	60	LP	610-0379
2.5KV-FA/26120C,D,E	120	60	LP	610-0382
2.5KV-FA/26120F,G,H,J	120	60	LP	610-0388
2.5KV-FA/26120K,L	100	60	LP	610-0388
2.8KV-FR/11351C,E	100	60	Gasoline	610-0386
2.8KV-FR/11351F,G,J,K	100	60	Gasoline	610-0394
2.8KV-FA/11574F,G,J,K	120	60	Gasoline	610-0388
2.8KV-FA/26100A,B	120	60	Gasoline	610-0375
2.8KV-FA/26100C,E	120	60	Gasoline	610-0382
2.8KV-FA/26100F,G,J	120	60	Gasoline	610-0388
3.0KVC-83A,B,C	120	60	Gasoline	610-0395
3.0KVC-84A,B,C	100	60	Gasoline	610-0396
2.5KVD-2089A,B	120	60	LP	625-4345
2.0KVD-3730B	230	50	LP	625-4562
2.8KVD-2090A	120	60	Gasoline	625-4345
2.3KVD-3729A	230	50	Gasoline	625-4562

Note – The diagonal line (/) or dash (–) in the model and specification number separates generator set characteristics from the specification number and letter. The specification number denotes customer requested options or deviations from a standard model. The specification letter advances (A to B, B to C, etc.) with major manufacturing changes.

Index

Arm, Governor Adjust, **11**
Arm, Rocker, **8**
Armature, Starter, **47, 49**

Baffle, Air, **26**
Baffle, Inlet (KV, KVD, Gasoline), **23**
Baffle, Inlet (KV, KVD, LP), **25**
Baffle, Seal, **26**
Base Mounting KV, **38**
Base Mounting KVD, **39**
Base, Housing (KV), **34**
Base, Housing (KVC), **36**
Base, Housing (KVD), **35**
Base, Mounting (KV), **34**
Base, Mounting (KVC), **36**
Base, Mounting (KVD), **35**
Base, Oil, **10**
Bearing, Ball, **7**
Bearing, Choke Flange (KV Begin Spec C), **13**
Bearing, Choke Flange (KVC, KVD, Gasoline), **14**
Bearing, Crankshaft Ball, **7**
Bearing, Generator Rotor Ball, **51**
Block, Cylinder, **6**
Block, Generator Brush, **45**
Boot, Inlet Baffle Insulation (KV, KVD, Gasoline), **23**
Boot, Inlet Baffle Insulation (KV, KVD, LP), **25**
Boot, Spark Plug (KV), **34**
Boot, Spark Plug (KVC), **54**
Boot, Spark Plug (KVD), **35**
Box, Control (KV Spec A–F), **52**
Box, Control (KVD and KV Begin Spec G), **53**
Brace, Generator, **43**
Bracket, Choke Mounting (KV Spec A, B), **12**
Bracket, Fuel Regulator (KV Begin Spec L and KVD Begin Spec B), **21**
Bracket, Lifting, **6**
Bracket, Muffler (KV Spec A–G), **29**
Bracket, Muffler (KVD), **32**
Bracket, Muffler Hanger (KVC), **31**
Bracket, Regulator, **19**
Bracket, Solenoid, **51**
Bracket, Starter, **45**
Bracket, Underfloor Mounting, **43**
Breaker, Circuit (KV Spec A–F), **52**
Breaker, Circuit (KVC), **54**
Breaker, Circuit (KVD and KV Spec Begin Spec G), **53**
Breather, Cylinder Head, **6**
Brush, Generator Brush Block, **45**
Bushing, Inlet Baffle Strain Relief (KV, KVD, Gasoline), **23**
Bushing, Inlet Baffle Strain Relief (KV, KVD, LP), **25**

Camshaft, **8**
Cap, Choke Dome (KV Begin Spec C), **13**
Cap, Choke Dome (KVC, KVD, Gasoline), **14**
Cap, Starter Drive, **47, 49**
Cap, Starter End, **47, 49**
Capacitor (KV Spec A–F), **52**
Carburetor (LP), **19**
Carburetor, Gasoline, **16**
Choke (KV Begin Spec C), **13**
Choke (KV Spec A, B), **12**
Clamp, Loop, **19**
Clamp, Muffler (KVD), **32**
Clip, "J", **9**
Clip, Choke "U" (KV Spec A, B), **12**
Clip, Governor Retainer, **11**
Clip, Rod End (KV Spec A, B), **12**
Clutch, Starter, **47**
Coil, Ignition (KV), **34**
Coil, Ignition (KVC), **54**
Coil, Ignition (KVD), **35**
Collar, Governor Control Lever, **11**
Components, Carburetor, **17**
Components, Starter (Begin Spec K), **49**
Components, Starter (Spec A–J), **47**
Conduit (KVC), **54**
Connector, Barbed Hose (KV, KVD, LP), **25**
Connector, Conduit (KVC), **54**
Connector, Plug (8 Pin) (KVC, KVD and KV begin Spec F), **67**
Connector, Receptacle (8 Pin) (KVC, KVD and KV begin Spec F), **67**
Connector, Receptacle (8 Pin) (KVC, KVD and KV begin Spec F), **67**
Control (KVC), **54**
Coupling, Anchor (KV, KVD, LP), **25**
Cover, Air Filter Element, **46**
Cover, Choke (KV Begin Spec C), **13**
Cover, Choke (KV Spec A, B), **12**
Cover, Choke (KVC, KVD, Gasoline), **14**
Cover, Choke Thermostat Element (KV Begin Spec C), **13**
Cover, Choke Thermostat Element (KVC, KVD, Gasoline), **14**
Cover, Cylinder Head, **9**
Cover, Housing (KV), **40**
Cover, Housing (KVD), **41**
Cover, Mounting Base (KVC), **36**
Cover, Rocker Switch (KV Spec C–F), **52**
Cover, Rocker Switch (KVC), **54**
Cover, Rocker Switch (KVD and KV Spec Begin Spec G), **53**
Cover, Starter Spring, **47**
Cover, Switch (KVC), **54**
Crankshaft, **7**

Diaphragm, Pull Off (KV Spec A, B), **12**
Diode, Remote Panel (KV Spec A–E), **55**
Door, Generator Scroll Preheat, **46**
Duct, Endbell Air, **45**

Edging, Underfloor Mounting, **43**
Elbow, Fuel Pump (KVC), **27**
Elbow, Inlet Baffle (KV, KVD, Gasoline), **23**
Elbow, Inlet Baffle (KV, KVD, LP), **25**
Elbow, Intake (Gasoline), **16**
Elbow, Male (KV, KVD, LP), **25**

Index

- Element, Air Filter, **46**
Element, Thermostat (KV Begin Spec C), **13**
Element, Thermostat (KV Spec A, B), **12**
Element, Thermostat (KVC, KVD, Gasoline), **14**
Endbell, **45**
Engine, Replacement, **6**
- Ferrule, Muffler Hanger Wire Rope (KVC), **31**
Filter, Fuel, **15**
Flange, Air Cleaner, **21**
Flange, Air Cleaner (Gasoline), **16**
Flange, Air Cleaner (LP), **19**
Flyweight, **8**
Foam, Carburetor (KVC, KVD), **16**
Foam, Fuel Filter, **15**
Fuse (KV Spec A–F), **52**
Fuse, Generator Harness (KV Spec C–E), **61**
Fuse, Generator Harness (KVC), **63**
Fuse, Generator Harness (KVD and KV Begin Spec F), **62**
Fuse, Generator Harness (KVD and KV, Begin Spec F), **62**
- Gasket, Carburetor (Gasoline), **16**
Gasket, Carburetor (LP), **19**
Gasket, Cylinder Head, **9**
Gasket, Drain Plug, **10**
Gasket, Exhaust (KVD), **32**
Gasket, Gearcase, **6**
Gasket, Governor Retainer Clip, **11**
Gasket, Head, **6**
Gasket, Housing Base (KV), **34**
Gasket, Housing Cover (KV), **40**
Gasket, Housing Cover (KVD), **41**
Gasket, Inlet Baffle Foam (KV, KVD, Gasoline), **23**
Gasket, Inlet Baffle Foam (KV, KVD, LP), **25**
Gasket, Intake Elbow (Gasoline), **16**
Gasket, Muffler (KV Begin Spec H), **30**
Gasket, Muffler (KV Spec A–G), **29**
Gasket, Muffler (KVC), **31**
Gasket, Muffler (KVD), **32**
Gasket, Oil Base, **10**
Gear, Camshaft, **8**
Gear, Crankshaft, **7**
Gear, Governor, **8**
Gear, Starter, **47**
Gearcase, **6**
Generator, **51**
Governor, **11**
Grommet, Generator Harness (KVC), **63**
Grommet, Housing Base (KVC), **36**
Grommet, Inlet Baffle (KV, KVD, Gasoline), **23**
Grommet, Inlet Baffle (KV, KVD, LP), **25**
Grommet, Inlet Baffle (KVD, Gasoline), **23**
Grommet, Inlet Baffle (KVD, LP), **25**
Grommet, Muffler Bracket (KVC), **31**
Guard, Housing Cover Air Inlet (KV), **40**
Guide, Push Rod, **8**
- Hanger, Tailpipe (KV), **33**
- Harness, AC Output (KVC), **54**
Harness, Adapter (KVC, KVD and KV Begin Spec F), **67**
Harness, DC (Z1, Z2, Z3, Z4) (KV Spec A, B), **60**
Harness, DC (Z1, Z4) (KV Spec C–E), **61**
Harness, DC (Z1, Z4) (KVD and KV Begin Spec F), **62**
Harness, Generator (J1, J2)(KVC), **63**
Harness, Generator (KV Spec A, B), **60**
Harness, Generator (KV Spec C–E), **61**
Harness, Generator (KVD and KV Begin Spec F), **62**
Harness, Generator (KVD), **64**
Harness, PCB, **65**
Harness, PCB (KV Spec C–F), **52**
Harness, PCB (KVC, KVD and KV Spec 51844), **65**
Harness, PCB (KVC), **54**
Harness, PCB (KVD and KV Spec Begin Spec G), **53**
Harness, Remote Panel (KVD and KV Begin Spec F), **57**
Harness, Remote Panel (Switch Only), **58**
Harness, Remote Switch Panel (KV Begin Spec F), **56**
Harness, Remote Wiring (KV Spec A–E), **59**
Harness, Remote Wiring (KVC, KVD and KV Begin Spec F), **67**
Harness, Wiring (Z1)(KVC), **65**
Head, Cylinder, **6**
Holder Assy, Brush, **49**
Holder, Fuse (KV Spec A–F), **52**
Holder, Generator Harness Fuse (KVC), **63**
Holder, Governor Spring, **11**
Hose, Breather, **9, 21**
Hose, Fuel (Gasoline), **15**
Hose, Fuel (LP), **19**
Hose, Vacuum (KV Spec A, B), **12**
Hose, Vapor, LP, **21**
Hose, Vent (LP), **19**
Hourmeter (KVD and KV Begin Spec F), **57**
Housing, Air Guide, **9**
Housing, Choke (KV Begin Spec C), **13**
Housing, Choke (KV Spec A, B), **12**
Housing, Choke (KVC, KVD, Gasoline), **14**
Housing, Scroll, **46**
Housing, Stator, **51**
Housing, Terminal (KVC, KVD and KV begin Spec F), **67**
Hub, Fan, **51**
- Indicator, Oil Level, **10**
Inlet Assy, **26**
Insulation, Inlet Baffle (KV), **38**
Insulation, Inlet Baffle (KVD), **39**
Insulation, Lower Exhaust Baffle (KV), **34**
Insulation, Upper Exhaust Baffle (KV), **38**
Insulation, Upper Exhaust Baffle (KVD), **39**
Insulator, Carburetor (Gasoline), **16**
Insulator, Carburetor (LP), **19**
Isolator, Vibration (KV Spec A), **51**
Isolator, Vibration (KV), **38**
Isolator, Vibration (KVC), **36**
Isolator, Vibration (KVD), **39**
- Key, Camshaft, **8**

Index

Key, Crankshaft, **7**
Key, Fan Hub, **51**
Kit, Carburetor, **16**
Kit, Carburetor (Conversion), **19**
Kit, Carburetor Service (LP), **19**
Kit, Exhaust (KV), **33**
Kit, Filter Cover, **15**
Kit, Fuel Tank (KV), **28**
Kit, Muffler (KVD), **32**
Kit, Muffler Exhaust (KV Begin Spec H), **30**
Kit, Piston Ring, **7**
Kit, Remote Adapter (KVC, KVD and KV begin Spec F), **67**
Kit, Remote Switch Panel (KV Begin Spec F), **56**
Kit, Remote Switch/Hourmeter Panel (KVD and KV Begin Spec F), **57**
Kit, Remote Switch/Voltmeter Panel (KVD and KV Begin Spec F), **58**
Kit, Starter Drive, **47, 49**
Kit, Underfloor Mounting, **43**
Kit, Underfloor Mounting (KV, KVD), **43**

Labels, **68**
Latch, Housing Cover Service Panel (KV), **40**
Latch, Housing Cover Service Panel (KVD), **41**
Lever, Governor, **11**
Lever, Governor Control (Gasoline), **11**
Link, Generator Scroll Preheat, **46**
Link, Pulloff (KV Spec A, B), **12**
Linkage, Choke (KV Begin Spec C), **13**
Linkage, Choke (KV Spec A, B), **12**
Linkage, Choke (KVC, KVD, Gasoline), **14**
Lock, Housing (KVC, KVD and KV begin Spec F), **67**
LPG Mixer, **21**

Magneto, **45**
Meter, Hour (KVC), **54**
Meter, Remote Panel Battery Condition (KV Spec A-E), **55**
Meter, Remote Panel Hour (KV Spec A-E), **55**
Mixer (KV Begin Spec L and KVD Begin Spec B), **21**
Muffler (KV Begin Spec H), **30**
Muffler (KV Spec A-G), **29**
Muffler (KVC), **31**
Muffler (KVD), **32**

O'Ring, End Bell, **51**
O'Ring, Oil Base, **10**

Paint, **68**
Panel Printed (KVD and KV Begin Spec F), **57**
Panel, Air Inlet (KVC), **26**
Panel, Housing Cover Service (KV), **40**
Panel, Housing Cover Service (KVD), **41**
Panel, Printed (KVD and KV Begin Spec F), **58**
Panel, Remote (KV Spec A-E), **55**
Panel, Remote Switch (KV Begin Spec F), **56**
Panel, Remote Switch Panel Printed (KV Begin Spec F), **56**
Panel, Remote Switch/Hourmeter (KVD and KV Begin Spec F), **57**

Panel, Remote Switch/Voltmeter (KVD and KV Begin Spec F), **58**
PCB Assy (KV Spec C-F), **52**
PCB Assy (KVD and KV Spec Begin Spec G), **53**
PCB Assy, Capacitor (KV, KVD, Gasoline), **23**
PCB Assy, Capacitor (KV, KVD, LP), **25**
PCB, Capacitor (KVC), **27**
PCB, Control (KVC), **54**
Pin, Cylinder Block Alignment, **6**
Pin, Decompression Spring, **8**
Pin, Piston, **7**
Pin, Starter Spiral Roll, **47**
Pin, Terminal (KVC, KVD and KV begin Spec F), **67**
Pipe, Exhaust (KVD), **32**
Pipe, Vacuum Hose (Gasoline), **16**
Piston, **7**
Plate, Circuit Breaker (KV Spec A-F), **52**
Plate, Circuit Breaker (KVD and KV Spec Begin Spec G), **53**
Plate, Governor Control Lever Pressure, **11**
Plug, Cavity (KVC, KVD and KV begin Spec F), **67**
Plug, Cavity (KVC, KVD and KV begin Spec F), **67**
Plug, Control Box Hole (KV Spec A-F), **52**
Plug, Oil Drain, **10**
Plug, Spark, **9**
Plug, Spark Plug Access Hole (KV), **34**
Plug, Spark Plug Access Hole (KVD), **35**
Pump, Electric Fuel (KV, KVD, Gasoline), **23**
Pump, Fuel (KVC), **27**

Rectifier, Generator Harness (KV Spec A, B), **60**
Rectifier, Generator Harness (KV Spec C-E), **61**
Regulator, **19**
Regulator, Fuel (KV Begin Spec L and KVD Begin Spec B), **21**
Regulator, Micro, **35**
Regulator, Voltage (KV), **34**
Regulator, Voltage (KVC), **27**
Relay, Disconnect (KV Spec A-F), **52**
Relay, Generator Harness (KV Spec A, B), **60**
Relay, Start Solenoid (KV, KVD, Gasoline), **23**
Relay, Start Solenoid (KV, KVD, LP), **25**
Relay, Start Solenoid (KVC), **27**
Relay, Stop (KV Spec A-F), **52**
Resistor, Charging, **45**
Resistor, Generator Harness (KV Spec A, B), **60**
Resistor, Generator Harness (KV Spec C-E), **61**
Resistor, Generator Harness (KVD and KV Begin Spec F), **62**
Resonator, Exhaust (KV), **28**
Retainer, Air Filter Element, **46**
Retainer, Choke Cover (KV Spec A, B), **12**
Retainer, Starter Clutch, **47**
Retainer, Starter Ring, **49**
Retainer, Starter Spring, **47**
Retainer, Valve Spring, **6**
Ring, Choke Extension Retaining (KV Spec A, B), **12**
Ring, Choke Retaining (KV Spec A, B), **12**

Index

- Ring, Collector, **51**
- Ring, Piston Retaining, **7**
- Rivet, Standoff (KV Spec C–F), **52**
- Rivet, Standoff (KVD and KV Spec Begin Spec G), **53**
- Rod, Connecting, **7**
- Rod, Governor, **11**
- Rod, Push, **8**
- Rope, Muffler Hanger Wire (KVC), **31**
- Rotor, Generator, **51**


- Scroll, **46**
- Scroll Assy, Generator, **46**
- Seal, Baffle Air (KVC), **26**
- Seal, Baffle Panel (KVC), **26**
- Seal, Cable (KVC, KVD and KV begin Spec F), **67**
- Seal, Generator Scroll Air Intake, **46**
- Seal, Mounting Base Air (KVC), **36**
- Seal, Mounting Base Frame (KVC), **36**
- Seal, Mounting Base Pan (KVC), **36**
- Seal, Oil, **7**
- Seal, Valve, **6**
- Shaft, Choke (KV Spec A, B), **12**
- Shaft, Flyweight, **8**
- Shaft, Governor Lever, **11**
- Shim, Camshaft, **8**
- Shim, Crankshaft, **7**
- Sleeve, Governor, **8**
- Slinger, Oil, **6**
- Solenoid, Shutdown (KV, KVD, LP), **25**
- Solenoid, Throttle Closing, **51**
- Spacer, Muffler Hanger (KVC), **31**
- Splasher (Crankshaft), **7**
- Spline, Starter, **47**
- Spring, Choke Adjust (KV Spec A, B), **12**
- Spring, Decompression, **8**
- Spring, Generator Brush Block, **45**
- Spring, Generator Stator, **45**
- Spring, Governor, **11**
- Spring, Governor Rod, **11**
- Spring, Regulator Hose (LP), **19**
- Spring, Starter Pinion, **47**
- Spring, Valve, **6**

- Standoff, PCB (KV Spec C–F), **52**
- Standoff, PCB (KVD and KV Spec Begin Spec G), **53**
- Starter, **45**
- Stator, Generator, **51**
- Stop, Governor Adjust, **11**
- Stopper, Governor Gear, **8**
- Strap, Ground (KV Spec A–G), **29**
- Strap, Ground (KVC), **37**
- Stud, B+, **27**
- Stud, Generator Mounting, **51**
- Stud, Generator Mounting (KV), **38**
- Stud, Generator Mounting (KVD), **39**
- Stud, Muffler Mounting (KV Begin Spec H), **30**
- Stud, Muffler Mounting (KV Spec A–G), **29**
- Stud, Muffler Mounting (KVC), **31**
- Stud, Muffler Mounting (KVD), **32**
- Stud, Vibration Isolator Mounting (KVC), **36**
- Switch, Low Oil Pressure, **6**
- Switch, Remote Panel Rocker (KV Spec A–E), **55**
- Switch, Remote Switch Panel Rocker (KV Begin Spec F), **56**
- Switch, Rocker (KV Spec A–F), **52**
- Switch, Rocker (KV Spec C–F), **52**
- Switch, Rocker (KVC), **54**
- Switch, Rocker (KVD and KV Begin Spec F), **58**
- Switch, Rocker (KVD and KV Spec Begin Spec G), **53**
- Switch, Rocker (KVD and KV, Begin Spec F), **57**
- System, Choke (KVC, KVD, Gasoline), **14**
- Tappet, **8**

- Transformer (KV Spec A–F), **52**
- Transformer (KVC), **54**
- Transformer (KVD and KV Spec Begin Spec G), **53**
- Tube, Breather, **9**
- Tube, Endbell, **45**
- Tube, Exhaust (KV), **33**
- Tube, Exhaust (KVC), **31**


- Tube, Oil Fill, **10**
- Valve, Exhaust, **6**
- Valve, Intake, **6**
- Voltmeter (KVD and KV Begin Spec F), **58**

Cylinder Block




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	100-3389	1	Engine, Replacement	11	308-1059	1	Switch, Low Oil Pressure (S2)
1	185-5193	1	Gearcase (Includes Pin)	12	185-5198	2	Bolt
2	185-5195	7	Bolt	13	185-5095	1	Gasket, Head
3	185-3175	2	Pin, Alignment	14	185-5097	2	Pin, Alignment
4	185-5194	1	Gasket, Gearcase	15	185-5202	1	Valve, Exhaust
5	185-3730	4	Bolt	16	185-5201	1	Valve, Intake
6	185-5199	1	Slinger, Oil	17	185-5200	1	Head, Cylinder (Includes Valve Guides and Valve Seats)
7	185-5196	1	Block, Cylinder	18	185-5099	1	Breather
8	403-4417-02	1	Bracket, Lifting	19	185-5096	4	Bolt, Cylinder Head
9	332-2634	1	Clamp, J (LP Sets)	20	185-5313	1	Seal, Intake Valve
10			Screw, Hex Head Thread Form	21	185-5203	2	Spring, Valve
	815-0709-01	1	KVC, Spec A	22	185-5204	2	Retainer, Valve Spring
			(M8 x 1.25 x 18mm)	23	185-5205	2	Cotter
	815-0508	1	KV, KVC (Begin Spec B) and KVD (5/16-18 x .75")				

Crankshaft



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-5112	1	Rod, Connecting (Includes Following Bolt and Splasher)	7	185-5116	1	Gear, Crankshaft
2	185-5113	2	Bolt, Connecting Rod	8	185-3088	1	Key, Crankshaft
3	185-5114	1	Splasher	9			Crankshaft
4	185-3085	1	Key, Crankshaft		185-5115	1	Spec A-B
5	185-5118	1	Bearing, Ball		185-7091	1	Begin Spec C
6			Shim, Crankshaft		185-7091	1	KVC, KVD
	185-4547	1	.10mm	10	185-5117	1	Bearing, Ball
	185-3371	1	.20mm	11	185-3761	1	Seal, Oil
	185-3366	1	.25mm	12	185-5109	1	Piston
	185-3367	1	.30mm	13	185-3416	2	Ring, Retaining
	185-3365	1	.35mm	14	185-5110	1	Kit, Piston Ring
	185-3368	1	.40mm	15	185-5111	1	Pin, Piston
	185-3370	1	.45mm				
	185-3369	1	.50mm				


Camshaft



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	526-2078	1	Washer	13			Gear, Camshaft KV
2	185-3674	1	Gear, Governor		185-5108	1	Spec A, B
3	526-2077	1	Washer		185-2914	1	Begin Spec C
4	150-2275	1	Stopper		185-2914	1	KVC, KVD
5	185-3675	1	Sleeve, Governor	14	185-3389	1	Key, Camshaft
6	185-5106	2	Tappet	15			Camshaft KV
7	150-2302	1	*Shaft, Flyweight		185-5107	1	Spec A, B
8	185-2731	1	*Flyweight		185-6375	1	Begin Spec C (Includes Parts Marked *)
9	185-6374	1	Pin, Decompression (KVC, KVD and KV, Begin Spec C)		185-6375	1	KVC, KVD(Includes Parts Marked *)
10	150-2305	1	*Pin, Decompression Spring	16	185-5103	2	Rod, Push
11	185-6373	1	Spring, Decompression(KVC, KVD and KV, Begin Spec C)	17	185-5104	1	Guide, Push Rod
12			Shim, Camshaft	18	185-5105	2	Stud
	185-4551	1	.10mm	19	185-5100	2	Arm, Rocker
	185-3399	1	.20mm	20	185-5101	2	Nut (Special)
	185-3393	1	.25mm	21	185-5102	2	Nut
	185-3394	1	.30mm				
	185-3392	1	.35mm				
	185-3395	1	.40mm				
	185-3396	1	.45mm				
	185-3397	1	.50mm				
	185-3398	1	.55mm				


* - Parts Included with Camshaft KVC, KVD and KV Beginning Spec C.

Cylinder Head Cover




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-5160	1	Housing, Top Air Guide	6	185-5156	1	Cover, Cylinder Head (Includes Breather Tube)
2	185-3730	3	Bolt	7	185-5157	1	Tube, Breather
3	503-1445-06	2	Clamp, Breather Hose	8	185-5159	4	Bolt
4			Hose, Breather KV	9	167-0263-02	1	Plug, Spark (E1)
	123-2044	1	Spec A-F	10	134-4636-01	1	Housing, Bottom Air Guide
	123-2129	1	Begin Spec G	11	518-0533	1	Clip, "J" (KV, KVC)
	123-2129	1	KVC, KVD Gas (See page 21 for LP)	12	823-0003-06	3	Screw, Pan Head Torx Thread Form (M6 x 1 x 12mm)
5	185-5158	1	Gasket, Cover				

Oil Base




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-5120	1	Gasket, Oil Base	7	185-5124	1	Tube, Oil Fill
2	185-5119	1	Base, Oil	8	185-5121	6	Bolt
3	185-5126	1	O'Ring	9	185-5122	4	Bolt
4	185-5125	1	Nut	10	185-3077	1	Gasket
5	185-5123	1	Indicator, Oil Level (Includes O'Ring)	11	102-1367	1	Plug, Oil Drain (M12 x 1.25mm)
6	185-3078	1	O'Ring				

Governor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	815-0261	2	Screw, Hex Washer Head Thread Form (1/4-20 x 1/2")(LP)	15	518-0576	2	Clip, Retainer
				16	185-5152	1	Spring, Rod
2	150-2450-02	1	Stop, Governor Adjust (LP)	17	185-5151	1	Rod, Governor
3	150-2449-02	1	Arm, Governor Adjust (LP)	18	150-2448	1	Gasket
4	526-0003	1	Washer, Flat (3/16") (LP)	19	185-7221	1	Washer, Flat
5	812-0087	1	Screw, Round Head Machine (8-32 x 1.5")(LP)	20	185-5150	1	Spring, Governor
				21	185-2366	1	Nut, Flanged (M8)
6	185-6955	1	Lever, Governor (Includes Parts Marked *)	22	185-6957	1	Washer, Spring Lock
				23	185-4499	1	Plate, Pressure
7	185-5148	1	*Nut	24	185-4498	1	Collar
8	185-6677	1	*Bolt	25	151-0700	1	Lever, Control (Includes Screw and Spring)(Gasoline Sets)
9	185-7090	1	*Clip, Retainer	26	150-2394	1	Spring
10	185-5145	1	*Washer, Flat	27	150-2514	1	Screw
11	150-2396	1	*Holder, Governor Spring	28	150-2286	1	Stud
12	150-2394	1	*Spring				
13	150-2395	1	*Screw				
14	185-5149	1	Shaft, Governor Lever (Includes Retainer Clip)	* - Parts Included in Governor Lever.			

Choke System (KV Spec A, B)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	518-0371	1	Clip, Rod End	13	823-0002-04	2	Screw, Pan Head Thread Forming with Socket Drive and IT Lockwasher (M4 x 0.7 x 12mm)
2	153-0600	1	Diaphragm, Pull Off	14	823-0006-01	2	Screw, Pan Head Thread Forming with Socket Drive and IT Lockwasher (M4 x 0.7 x 30mm)
3	518-0450	1	Clip, "U"	15	153-0595	1	Screw, Choke Adjust
4	503-1338	1	Hose, Vacuum	16	153-0610	1	Spring, Choke Adjust
5	823-0003-05	2	Screw, Socket Drive Pan Head (M6 x 1 x 14mm)	17	526-0008	1	Washer, Flat
6	153-0604	1	Choke (H1)	18	518-0129	1	Ring, Extension Retaining
7	153-0599	1	Link, Pull Off	19	153-0605-02	1	Bracket, Choke Mounting
8	153-0611	1	Housing, Choke	20	153-0598	1	Shaft, Choke
9	518-0532	1	Ring, Choke Retaining Adjust	21	153-0596	1	Linkage, Choke
10	153-0554	1	Element, Thermostat				
11	153-0602	1	Cover, Choke (Includes Choke Heater Element, Washers and Heater Spider)				
12	153-0609	1	Retainer, Choke Cover				


Choke System (KV Begin Spec C)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	153-0659	1	Cover, Element
2	517-0305	1	Cap, Dome
3	153-0647-02	1	Cover, Choke
4	526-0003	2	Washer, Flat (#8)
5	860-2005	2	Nut, Lock Flange (M4)
6	153-0645	1	Linkage, Choke


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	153-0640	1	Element, Thermostat
8	232-3720	1	Bearing, Choke Flange
9	153-0651-02	1	Cover, Choke
10	850-0020	1	Washer, Lock (#6)
11	808-0008	1	Screw, Pan Head (#6 x 3/8")

Choke System **KVC, KVD** **(Gasoline)**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	153-0693	1	Linkage, Choke	8	526-0003	2	Washer, Flat (#8)
2	232-3720	1	Bearing, Choke Flange	9	153-0651-02	1	Cover, Choke
3	153-0640	1	Element, Thermostat	10	808-0008	3	Screw, Pan Head Sheet Metal (#6-32 x .38)
4	153-0659	1	Cover, Element	11	850-0020	3	Washer, Lock (#6)
5	517-0305	1	Cap, Dome	12	153-0692-02	1	Cover, Choke Housing
6	153-0691-02	1	Housing, Choke				
7	860-2005	2	Nut, Lock Flange (M4 x .7)				

Fuel Filter Gasoline



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149-2137	1	Filter, Fuel	7	541-0558	1	Kit, Filter Cover (Includes Fuel Filter Foam, Foam Cover and Fuel Filter Foam Shown on Carburetor Page)
2	149-2633	1	KV				
	149-2633	2	KVC, KVD				
3	149-2636	1	Cover, Fuel Filter (KVC, KVD)	8			Sleeving, Convoluted (21")
4			Hose, Upper Fuel		898-1196-26	1	KV, KVD
	503-1418	1	KV Spec A (85mm)		898-1196-27	1	KVC
	503-1777	1	KV Begin Spec B (70mm) and KVC, KVD Begin Spec A	9	898-1196-25	1	Sleeving, Convoluted (KVD, 5-3/4")
5	503-0731	4	Clamp, Black Hose				
6			Hose, Lower Fuel				
			KV				
	503-1418	1	Spec A (85mm)				
	503-1777	1	Spec B (70mm)				
	503-1824	1	Begin Spec C (600mm) KVC (279mm)				
	503-1777	1	Spec A				
	503-2146	1	Begin Spec B				
	503-2300	1	KVD (825mm) Begin Spec A				

Gasoline Carburetor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0705	1	Kit, Carburetor (KV Begin Spec E, KVC Begin Spec C and KVD Begin Spec A)	7	140-2981	2	*Gasket, Carburetor Insulator
1	185-5129	2	Bolt (M6 x 1 x 80mm)	8	185-5134	1	KV Spec A-D
2	740-1004	2	Washer, Flat (M6)		140-2980	1	KV Begin Spec E, KVC Begin Spec C, KVD Begin Spec A
3	145-0589	1	Gasket, Carburetor Flange	9	185-5135	1	Elbow, Intake (Includes Vacuum Hose Pipe)
4			Flange, Air Cleaner	10	185-5136	1	Pipe, Vacuum Hose (KV, Spec A & B with hole)
	185-5127	1	KV Spec A-D	11	185-5137	2	Gasket, Intake Elbow
	140-2978	1	KV Begin Spec E, KVC Begin Spec C, KVD Begin Spec A	12	185-5138	1	Insulator
5			Gasket, Flange KV	13	185-5139	2	Bolt, Flange
	185-5128	1	Spec A-D	14	149-2633	1	+ Foam, Fuel Filter (KVC, KVD)
	140-2979	1	* Begin Spec E, KVC, KVD				
6			Carburetor KV				
	146-0540	1	Spec A, B				
	146-0569	1	Spec C-D				
	146-0802	1	* Begin Spec E (Includes Gaskets Marked *)				
	146-0802	1	KVC Begin Spec A (Includes Parts Marked *)				
	146-0802	1	KVD Begin Spec A (Includes Parts Marked *)				

* - Parts Included when ordering carburetor 146-0802 or carburetor kit 146-0705.

+ Filter Foam Included in Filter Cover Kit Listed on Fuel Filter Page.


Gasoline Carburetor *Components **(KV Spec A-B)**



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0540	1	Carburetor	16	185-5179	1	Float
1	185-5165	2	Screw	17	185-5175	1	Body, Float
2	185-5164	1	Valve, Choke	18	185-5183	2	O'Ring
3	185-5168	1	Shaft, Choke	19	185-5182	1	Adjuster
4	185-5166	1	Jet, Pilot	20	185-5181	1	Cap
5	185-3245	1	Spring	21	185-5184	1	Screw
6	185-5167	1	Adjuster	22	185-5172	1	Plate, Spring
7	185-5170	1	Shaft, Throttle	23	185-5314	1	Bolt, Float Body
8	185-5163	1	Valve, Throttle	24	185-5176	1	O'Ring
9	185-4558	2	Screw	25	185-5177	1	Washer
10	185-5186	1	Seal	26	185-5185	1	Clip (Obsolete)
11	185-4563	1	Spring	27	185-5173	1	Needle
12	185-5169	1	Screw				
13	185-5178	1	Packing, Chamber - Float				
14	185-5174	1	Pin				
15	185-5180	1	Nozzle, Main				

* - Service Parts Not Available for Other Carburetors.

LPG Carburetor/Regulator **(KV Spec A-K and KVD Spec A)**




LPG Carburetor/Regulator (KV Spec A-K and KVD Spec A-B)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Carburetor		541-0808	1	~ Spec H-J (11.8")
			KV		503-2143-05	1	~ Begin Spec K (300mm)
	146-0545	1	Spec A,B (Includes Parts Marked *)		503-2143-05	1	~ KVD (300mm)
	146-0570	1	Spec C, D	19	503-1133	2	Clamp, Hose
	146-0721	1	Spec E, F, G (Includes Gaskets Marked ◇)	20	503-2004	1	Hose, Fuel (25")
	146-0770	1	Spec H	21			Bracket, Regulator
	146-0801	1	Begin Spec J-K (Includes Parts Marked ~)		148-0932-02	1	KV
			KVD		148-1124-02	1	Spec A-G
	146-0801	1	Spec A		148-1124-02	1	Spec H-K
	146-0840	1	Begin Spec B		148-1124-02	1	KVD
2	140-2979	1	◇Gasket, Flange	22	821-0004	2	Screw, Self-Locking Hex Head Flange (#10-32 x 5/16)
3	140-2981	2	◇Gasket, Carburetor	23	823-0003-05	2	Screw, Pan Head (M6 x 1 x 14mm)
4			Flange, Air Cleaner	24	146-0753	1	Kit, Carburetor (Conversion) (Used to Replace KV Spec A-D)
			KV				Carburetor and Components) (Includes Parts Marked @)
	185-5127	1	Spec A-D		140-2978	1	@ Flange, Air Cleaner
	140-2978	1	Spec E-K		140-2979	1	@ Gasket, Air Cleaner
	140-2978		KVD		140-2980	1	@ Insulator
5			Insulator		140-2981	2	@ Gasket, Insulator
			KV		145-0589	1	@ Gasket, Carburetor Flange
	185-5134	1	Spec A-D		146-0667	1	@ Carburetor, LPG Emission
	140-2980	1	Spec E-K		502-1300	1	@ Reducer, Hose Barb
	140-2980	1	KVD		503-0731	2	@ Clamp, Hose
6	145-0589	1	Gasket, Carburetor Flange		503-1199	1	@ Hose, Vent
7	740-1004	2	Washer, Flat		503-1851	4	@ Clamp, .69 Hose
8	185-5129	2	Bolt (M6 x 1 x 80mm)		503-2004	1	@ Hose, LPG Fuel (12")
9	880-0528	2	Spring, Regulator Hose(Used on KV during Spec F, G Only)		880-0528	1	@ Spring, Regulator Hose
10	503-1133	2	~Clamp, Hose	25	146-0760	1	Kit, Carburetor Service (Used to Service KV Spec A-D Carburetors (Includes Parts Marked +))
11	146-0576	1	+*Spring, Load Adjust				
12	146-0575	1	+*Screw, Load Adjust	26	332-1356	1	Clamp, Loop
13	146-0574	1	+*Spring, Idle Adjust	27	815-0261	1	Screw
14	146-0573	1	+*Screw, Idle Adjust				
15			Hose, Vent				
			KV				
	503-2004	1	Spec A-D (4.2")				
	503-1199	1	Begin Spec E (No Shorter Than 23")				
	503-1199	1	KVD (No Shorter Than 23")				
16	503-0731	2	~Clamp, Hose				
17			Regulator				
			KV				
	148-0963	1	Spec A-D				
	148-1012	1	Spec E-G				
	148-1125	1	~ Begin Spec H				
	148-1125	1	~ KVD				
18			Hose, Outlet Fuel				
			KV				
	503-2004	1	Spec A-D (4.4")				
	503-2008	1	Spec E-G (4/38")				


* - Parts Included with KV Spec A, B Carburetor.
~ - Parts Included with KV Spec J-K Carburetor.
◇ - Gaskets Included with KV Spec E-G Carburetor.
@- Parts Included in LPG Conversion Carburetor Kit.
+ - Parts Included in LPG Carburetor Service Kit.

LPG Mixer
LP (KV FR11540, FA26120, FR26119 Begin Spec L
and KVD 2089 3730 Begin Spec B)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-1260	1	Regulator, Fuel	12	821-0010	2	Screw, Locking Hex Head
	148-1284	1	Obsolete				Flange (1/4-20UNF x 12")
			2KVFR26119,	13	145-0589	1	Gasket, Carb Flange
			2.5KVFR11540,	14	740-1004	2	Washer, Flat (M6)
			2.5KVFA26120,	15	185-5129	2	Bolt, (M6 x 1 x 80mm)
			2.5KVD2089, 2KVD3730	16			Flange, Air Cleaner
2	123-2129	1	Hose, Breather		140-3499-02	1	Obsolete
3			Mixer		140-2978	1	LPG 60 and 50 Hz
	146-0830	1	Obsolete	17	140-2979	1	Gasket, Air Cleaner
	146-0840	1	LPG (60Hz)	18	140-2981	2	Gasket, Insulator
	146-0841	1	LPG (50Hz)	19	140-2980	1	Insulator
4	503-1445-06	2	Clamp, Hose	20	185-5135	1	Elbow, Intake
5	503-1418	1	Hose, Fuel	21	740-1004	2	Washer, Flat (M6)
6	148-1267-02	1	Bracket, Fuel Regulator	22	185-5129	2	Bolt, Flange
7	813-0103	1	Screw, Round Head (Mach)	23	185-5137	2	Gasket, Intake Elbow
8	850-0030	1	Washer, Spring Locking	24	185-5138	1	Insulator
9	815-0261	1	Screw, Hex Thread Form	25	503-0446	2	Clamp, Hose
10	823-0003-04	1	Round, Head (Mach)	26	503-2143-08	1	Hose, Vapor, LP
11	148-1261-02	1	Bracket, Fuel Regulator	27	503-0731	1	Hose, Clamp


**Inlet Baffle
KV, KVD
(Gasoline)**



**Inlet Baffle
KV, KVD
(Gasoline)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Baffle, Inlet (Includes Conduit Elbow)	18			Pump, Electric Fuel (E2)
			KV				KV
	405-3785	1	Spec A		149-2140	1	Spec A,B
	405-4321-02	1	Spec B		149-2588	1	Spec C-E
	405-4417-02	1	Spec C-E		149-2615	1	Spec F-K
	405-5827-02	1	Spec F-K		149-2615	1	FR11540, FR26119, FA26120, Begin Spec L and KVD 2089, 3730 3729
	405-6973-04	1	FR11540, FR26119, FA26120 Begin Spec L and KVD 2089, 3730 3729				Begin Spec B
			Begin Spec B	19			Clamp
2	331-0521	1	Elbow, 90° Conduit		332-2900	1	KV
3	823-0001-01	2	Screw, Pan Head Trox (M3)		332-1420	1	Spec A,B
4	356-0070	1	Clamp, Capacitor Mount		332-1420	1	Begin Spec C
5	300-4329	1	PCB Assy, Capacitor	20	508-0179	1	KVD
6	812-0066	1	Screw, Round Head Machine (#6-32 x .75")	21	323-1507	1	Bushing, Strain Relief
7	860-0006	1	Nut, Hex (#6-32)	22	167-1636	1	Bushing, Strain Relief
8	405-5812	1	Gasket, Foam	23	508-1168	1	Boot, Insulation (B+ Lead)
9	870-2054	6	Nut, Hex Flange Lock (M6 x 1mm)	24	508-1174	1	Grommet (KVD)
10	508-0293	1	Grommet	25			Grommet (KVD)
11	868-0002	2	Nut, Hex (5/16-24)		149-2120	1	Line, Inlet Fuel
12	850-0045	2	Washer, Spring Lock (5/16")		149-2327	1	KV
13	332-2897	2	Terminal		149-2327	1	Spec A,B
14	307-2586	1	Relay, Start Solenoid	26	508-0289	2	Begin Spec C
15	502-0002	1	Elbow, Inverted Male (90°)				KVD
16	856-0006	2	Washer, EIT Lock (1/4")	27	149-2300	2	Grommet, Fuel Line
17	502-0313	1	Elbow, 90°Hose (KV Spec C-K and KVD)(Not used on KV Spec A,B)				KV Spec A, B
							Line Fuel (Includes Nut)
							KV Spec A, B


Inlet Baffle **KV, KVD** **(LP)**



Inlet Baffle
KV, KVD
(LP)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Baffle, Inlet (Includes Elbow)	16	332-1420	1	Clamp Begin(KVD and KV Spec C)
	405-5828-02	1	KV				
	405-6973-03	1	KVD	17	508-0179	1	Bushing, Strain Relief
2	331-0521	1	Elbow, 90° Conduit	18	323-1507	1	Bushing, Strain Relief
3	823-0001-01	2	Screw, Pan Head (M3)	19	167-1636	1	Boot, Insulation (B+ Lead)
4	356-0070	1	Clamp, Capacitor Mount	20	502-1162	1	Connector, Barbed Hose
5	300-4329	1	PCB Assy, Capacitor	21	307-2961	1	Solenoid, Shutdown
6	812-0066	1	Screw, Round Head Machine (#6-32 x .75")	22	502-1133	1	Coupling, Anchor
7	860-0006	1	Nut, Hex (#6-32)	23	149-2524-01	1	Line, Fuel Inlet
8	405-5812	1	Gasket, Foam	24	502-1140	1	Elbow, Male (.25 x 90°)
9	508-1122	1	Grommet (KVD)	25			Clamp, Hose
10	870-2054	4	Nut, Hex Flange Lock (M6 x 1mm)		503-1133	2	Spec C
11	508-0293	1	Grommet		503-2309	2	Begin Spec L
12	868-0002	2	Nut, Hex (5/16-24)	26			Hose, Fuel Line (.375 ID x 25")
13	850-0045	2	Washer, Spring Lock (5/16")				KV
14	332-2897	2	Terminal		503-2004	1	Spec C
15	307-2586	1	Relay, Start Solenoid (K1)		503-2143-02	1	Begin Spec L
					503-2143-02	1	KVD


Air Inlet Panel KVC



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-6451	1	Inlet Assy (Includes Parts Marked +)	10	405-6490-01	1	*Seal, Panel (312.5 x 25.4mm)
2	405-6454	1	+ Seal, Air (187mm x 30mm)	11	405-6490-02	1	*Seal, Panel (59.2 x 25.4mm)
3	405-6509	1	+ Seal, Air (25mm)	12	405-6490-03	1	*Seal, Panel (65 x 20mm)
4	405-6448-02	1	+ Seal, Air (195.1mm x 30mm)	13	405-6481-02	1	Baffle, Seal
5	405-6448-01	1	+ Seal, Air (347mm x 30mm)	14	821-6002-02	6	Screw, Lock Flange (M6 x 1 x 12mm)
6	405-6450	1	+ Seal, Air (367mm x 170mm)				
7	405-6446-02	1	Baffle, Air				
8	405-6487	1	Panel Assy (Includes Parts Marked *)				
9	405-6486	1	*Seal, Panel (69 x 25.4mm)				


* - Parts Included in Panel Assy.
+ - Parts Included in Baffle Assy.

Fuel Pump/Start Solenoid Relay KVC




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149-2331-03	1	Pump, Electric Fuel	11	305-0897	1	Regulator, Voltage
2	502-0313	2	Elbow, 90 Hose(.25 x .125 x 27")	12	520-1018-02	1	Stud, B+
3	856-0006	4	Washer, EIT (1/4")	13	864-0002	4	Nut, Hex Jam (5/16-18)
4	823-0002-04	2	Screw, Pan Head Torx (M4 x 0.7 x 12mm)	14	526-0115	4	Washer, Flat (5/16")
5	812-0066	1	Screw, Slotted Head (6.32 x .75)	15	508-0332	2	Washer, Phenolic
6	300-4329	1	PCB Assy, Capacitor	16	853-0016	4	Washer, EIT Lock
7	356-0070	1	Clamp, Capacitor Mounting	17	307-2570	1	Relay, Start Solenoid
8	860-0006	1	Nut, Hex (#6-32)	18	332-2897	2	Terminal
9	860-2005	2	Nut (M4 x 0.7mm)	19	850-0045	2	Washer, Spring Lock (5/16")
10	823-0003-05	4	Screw, Pan Head Torx Thread Form (M6 x 1 x 14mm)	20	868-0002	2	Nut, Hex (5/16-24)
				21	821-0010	2	Screw, Lock Head (1/4-20 x 1/2")

Fuel Tank Kit KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	415-0511	1	Tank, Fuel (6 Gallon)	6	503-0731	4	Clamp, Hose
2	505-0007	1	Bushing, Reducer (1/4" x 1/8")	7	502-0397	1	Coupling, Quick Disconnect Female
3	504-0169	1	Valve, Shutoff (1/8")	8	502-0398	1	Coupling, Quick Disconnect Male
4	502-0395	1	Connector, Barbed Hose (1/8")				
5	503-1199	1	Hose, Fuel (1/4" ID x 14")				

Resonator KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-2449	1	Resonator, Exhaust

Muffler (KV Spec A-G)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-3436-01	1	Muffler LP	6	155-2301-02	1	Bracket, Muffler
	155-3436-02	1	Gasoline (Includes Choke Housing)	7	337-0049	1	Strap, Ground
2	870-2055	2	Nut, Hex Flange Locking (M8)	8	856-0008	1	Washer, EIT Lock (5/16")
3	870-2054	2	Nut	9	155-2233-02	1	Bracket, Muffler
4	821-2045	2	Screw, Lock Flange (M8 x 1-1/4 x 16mm)	10	332-2634	1	Clamp, "J" (LPG Units Only)
5	815-0709-01	4	Screw, Hex Head Thread Forming (M8 x 18mm)	11	155-2953	1	Gasket, Muffler
				12	185-5098	2	Stud, Muffler Mounting

Muffler (KV Begin Spec H)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Kit, Muffler Exhaust	2	815-0508	4	Screw, Hex Head Thread Form (5/16-18 x .75")
	155-3436-01	1	LP	3	870-2054	2	Nut Supplied with Engine
	155-3436-02	1	Gasoline	4	155-2953	1	Gasket, Muffler (Included with Engine)
			Muffler (Includes Choke Housing)	5	185-5098	2	Stud, Muffler Mounting
	155-3435-01	1	LP				
	155-3435-02	1	Gasoline				


Muffler KVC



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-3314	1	Muffler, Exhaust	11	880-0539	2	*Ferrule, Wire Rope
2	155-3315	1	Tube, Exhaust	12	880-0538	1	*Rope, Wire (150mm)
3	155-1256	2	Clamp, Muffler (Includes Clamp, "U" Bolt and Nuts)	13	718-1036	1	Screw, Hex Head Cap (M8 x 1.25)
4	800-2034	2	Screw, Hex Head Cap (M6 x 1 x 20mm)	14	526-2100	1	Washer, Flat (M8)
5	155-2953	1	Gasket, Muffler	15	750-1006	1	Nut, Hex (M8 x 1.25)
6	155-3313	1	Tube, Flex Exhaust	16	155-1256	1	Clamp, Muffler (Includes Clamp, "U" Bolt and Nuts)
7	870-2054	2	Nut, Lock Flange	17	155-3312	1	Tube, Exhaust
8	155-3342-02	1	Bracket, Muffler Hanger (Includes Parts Marked*)	18	870-2054	2	Nut, Lock Flange
9	508-0068	1	*Grommet, Rubber Obsolete	19	185-5098	2	Stud, Muffler Mounting
10	370-0116-02	1	*Spacer, Muffler Hanger Obsolete				


* - Parts Included in Hanger, Not Sold Separate.

Exhaust Kit KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-2325	1	Kit, Exhaust Tubing (Includes Parts Marked *)	8	155-2322	1	#Tube, Exhaust (356mm)
2	155-2324	1	Kit, Exhaust Tubing (Flexible) (Includes Parts Marked #)	9	155-2174	2 +~#*	Hanger, Tailpipe (Included in all Kits Listed)
3	155-2771	1	Kit, Exhaust Tubing (Flexible) (Includes Parts Marked ~)	10	155-1239	1 +~#	Clamp (Marked 1-1/2")
4	155-2425	1	Kit, Vertical Exhaust Tubing Extension (Includes Parts Marked +)	11	155-1256	1 +~#*	Clamp (Marked 1-1/8") (Included in all Kits Listed)
5	155-2772	1	~Tube, Straight Exhaust (300mm)	* - Parts Included in 155-2325 Exhaust Tubing Kit. # - Parts Included in 155-2324 Flexible Exhaust Tubing Kit. ~ - Parts Included in 155-2771 Flexible Exhaust Tubing Kit. + - Parts Included in 155-2425 Vertical Exhaust Tubing Extension Kit.			
6	155-2323	1	*Tube, Exhaust (635mm)				
7	155-2665	1	+Tube, Exhaust (242mm)				

Mounting Base KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Base, Housing	9	166-0784-S0	1	Coil, Ignition (T1) (Includes Lead, Cap, and Boot)
	405-3794	1	Spec A	10	860-2005	2	Nut, Hex (M4)
	405-4323-02	1	Spec B	11	517-0254	1	Plug, Spark Plug Access Hole
	405-4423-02	1	Begin Spec C	12	856-0002	2	Washer, EIT Lock (#8)
2	895-0305-04	1	Gasket (504mm x 6mm x 10mm)	13	823-1001-04	2	Screw, Pan Head Socket Drive (M4 x 12mm)
3	405-3797	1	Insulation, Lower Exhaust Baffle	14	870-2054	1	Nut, Locking Hex Flange (M6)
4	823-1002-01	2	Screw, Pan Head Socket	15	856-0006	2	Washer, EIT (1/4")
5	305-0767-02	1	Clamp, Regulator	16	518-0728	2	Clip (Begin Spec L)
6	167-0267	1	Terminal, Spark Plug				
7	167-0265	1	Boot, Spark Plug				
8			Regulator, Voltage Spec A, B				
	305-0830-02	1	50 Hz				
	305-0852	1	60 Hz				
	305-0897	1	Begin Spec C				

Mounting Base KVD




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-6938-02	1	Base, Housing	8	166-0784-S0	1	Coil, Ignition (T1)(Includes Lead, Cap, and Boot)
2	895-0305-04	1	Gasket Foam (504mm x 6mm x 10mm)	9	856-0002	2	Washer, EIT Lock (#8)
3	823-1002-01	1	Screw, Pan Head Torx (M6 x 1 x 12mm)	10	860-2005	2	Nut, Hex (M4)
4	305-0897		Regulator, Micro Voltage	11	517-0254	1	Plug, Spark Plug Access Hole
5	167-0267	1	Terminal, Spark Plug	12	870-2054	7	Nut, Locking Hex Flange (M6 x 1mm)
6	167-0265	1	Boot, Spark Plug	13	856-0006	2	Washer, EIT Lock (1/4")
7	823-0002-06	2	Screw, Pan Head Torx (M4 x 0.7 x 18mm)	14	518-0728	2	Clip (Begin Spec B)

Mounting Base KVC




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-6444-02	1	Base, Housing	10	405-6489	1	Seal, Pan (293.5mm)
2	508-1122	1	Grommet (19mm ID)	11	508-1116	1	Grommet, Oval
3	870-2054	3	Nut, Hex Flange Locking (M6)	12	405-6485	1	Seal, Pan (338.2mm)
4	402-0547	3	Isolator, Vibration	13	405-6510	1	Seal, Pan (98mm)
5	870-2156	3	Nut, Pan Head with Internal Thread (M8 x 1.25 x 11.50mm)	14	405-6494	1	Seal, Frame (434.3mm)
6	508-0258	1	Grommet (1-1/4" ID)	15	405-6507	1	Seal, Air (110mm)
7	508-0008	2	Grommet (1/2" ID)	16	402-0601-02	2	Isolator, Vibration With Yellow Dot (Generator End)
8	405-6447-02	1	Cover, Base		402-0601-01	1	With Blue Dot (Engine End)
9	821-6002-02	11	Screw, Hex Head Sems (M6 x 1 x 12mm)	17	520-2210	3	Stud, Mounting

Ground Strap
KVC




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	856-0008	3	Washer, EIT Lock (5/16")	3	337-0049	1	Strap, Ground
2	526-0432	1	Washer, Spring Conical (Spec A Only)	4	815-0709-01	2	Screw, Hex Head Thread Form (M8 x 1.25 x 18mm)

Base Mounting KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	402-0547	3	Isolator, Vibration	10	337-0049	1	Strap, Bond
2	870-2156	3	Nut, Pan Head with Internal Thread (M8 x 11.50mm)	11	870-2054	4	Nut, Hex Flange Locking (M6) Spec A
3	870-0212	1	Nut, Hex Flange Locking (1/4-20) Spec A		870-2054	6	Spec B
4	402-0601-02	2	Isolator, Generator Mount Vibration (With Yellow Dot)		870-2054	7	Spec C
5	520-2210	3	Stud, Generator Mounting	12	856-0006	1	Washer, EIT Lock (1/4")
6	402-0601-01	1	Isolator, Engine Mount Vibration (With Blue Dot)	13	856-0008	1	Washer, EIT (5/16)
7	405-3816	1	Insulation, Inlet Baffle	14	740-1004	1	Washer, Flat (M6) (K3 Relay Mounting)
8	815-0508	1	Screw, Thread Form (5/16-18 x .75)	15	750-1004	1	Nut, Hex (M6) (K3 Relay Mounting)
9	821-2033	1	Screw, Hex Washer Head Locking (M6 x 10mm)	16	405-3796	1	Insulation, Exhaust Baffle (Upper)

Base Mounting KVD




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	870-2054	3	Nut, Hex Flange Locking (M6)	8	405-6982	1	Insulation, Inlet Baffle (Inlet)
2	402-0547	3	Isolator, Vibration	9	815-0508	1	Screw, Thread Form (5/16-18 x .75")
3	870-2156	3	Nut, Pan Head with Internal Thread (M8 x 11.50mm)	10	821-2033	1	Screw, Hex Washer Head Lock Flange (M6 x 10mm)
4	870-0212	1	Nut, Hex Flange Locking (1/4-20)	11	856-0006	1	Washer, EIT Lock (1/4")
5	402-0601-02	2	Isolator, Generator Mount Vibration (With Yellow Dot)	12	337-0049	1	Strap, Bond
6	520-2210	3	Stud, Generator Mounting	13	856-0008	1	Washer, EIT (5/16)
7	402-0601-01	1	Isolator, Engine Mount Vibration (With Blue Dot)	14	155-3541	1	Insulation, Exhaust
				15	850-0040	1	Washer, Split Lock (1/4")
				16	862-0001	1	Nut, Hex (1/4-20)

Housing Cover KV




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-4328	1	Cover, Housing Spec A	6	895-0305-01	1	Gasket, Foam (Spec A) (90mm x 7.9mm x 4.8mm) Obsolete
	405-4326	1	Begin Spec B	7	405-3789	1	Guard, Air Inlet (Spec A)
2	405-3790-S0	1	Panel, Service(Includes Gasket and Latch)	8	815-0675	1	Screw, Thread Cutting Socket Drive (Spec A) (#8-16 x 12.3mm)
3	405-3784	1	Gasket	9	815-0685	4	Screw, Truss Head (M6 x 8mm)
4	406-0612	2	Latch				
5	895-0305-02	1	Gasket, Foam (Spec A) Obsolete (395mm x 7.9mm x 4.8mm)				

Housing Cover KVD



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	405-6956	1	Cover, Housing	3	405-3784	1	Gasket
2	405-3790-S0	1	Panel, Service (Includes Gasket and Latch)	4	406-0612	2	Latch
				5	815-0685	4	Screw, Truss Head (M6 x 8mm)


Underfloor Mounting Kit KV, KVD



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Kit, Underfloor Mounting (Includes all Parts Listed)
	403-2689	1	KV
	541-0661	1	KVD
2	403-2679-02	2	Bracket
3	526-0174	11	Washer, Flat (3/8")
4	800-0048	6	Screw, Hex Head Cap (3/8-16 x 3/4")
5	870-0281	2	Nut, Locking Head Flange (3/8-16)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
6	508-1047	1	Edging
7			Brace, Generator
	403-2680-02	2	KV
	403-4668-02	2	KVD
8	526-0077	1	Washer, Flat (3/8")
9	800-0050	1	Screw, Hex Head Cap (3/8-16 x 1")


Endbell



Endbell

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Starter (B1) (See Separate Page for Components)	16	212-1276-03	2	Spring
	191-1798	1	KV Spec A-J and KVC Spec A-B	17	214-0103	2	Brush
	191-2312	1	KV Begin Spec K, KVC Begin Spec C and KVD Begin A	18	823-0002-09	4	Screw, Pan Head (M4 x 16mm)
	191-2351	1	Supercede 191-1798 and 191-2312	19	526-0003	2	Washer, Flat (3/16")
2			Washer, Flat (M8)	20	160-1358-S0	1	Magneto
	740-1006	4	KVD Spec A-G	21			Tube, Endbell
	740-1006	2	KVC, KVD and KV, Spec H-K		232-4008	1	KV Spec A-K , KVC Spec A-B KVD Spec A (Gasoline)
3	815-0781	2	Screw, Hex Head Washer (M8 x 1.25 x 30mm)		505-2119	1	KV FR11540 FR26119 FA26120 Begin Spec L and KVD 2089, 3730 Begin Spec B (LP)
4	853-0013	1	Washer, ET Lock (1/4")	22	815-0888	3	Screw, Phillips Head (#6-20 x 1/2")
5	191-1825-02	1	Bracket, Starter	23	134-4637	1	Duct, Air
6	870-0236	1	Nut, Lock (#10-32)	24			Endbell
7	823-0003-03	1	Screw, Pan Head (M6 x 1 x 20mm)				KV
8	862-0001	1	Nut, Hex (1/4-20)		211-0408	1	Spec A,B
9	850-0040	1	Washer, Spring Lock (1/4")		211-0450	1	Spec C-F
10	750-1006	2	Nut, Hex (M8 x 1.25) (KV, Spec A-H)		211-0486	1	Spec G-K
11	304-0796	2	Washer, Centering (KV only)		211-0527	1	Begin Spec J
12	304-0797	1	Resistor, Charging (R1) (KV only)		211-0486	1	KVC
13	815-0660	1	Screw, Hex Head Thread Forming Socket Drive (#10-32 x 2 1/2")(KV only)		211-0527	1	Spec A-B
14	232-3278	4	Spring, Stator		211-0486	1	Begin Spec C
15	212-1285	1	Block, Generator Brush (Includes Spring and Brush)		211-0527	1	KVD
							Spec A
							3729 A, Begin Spec B

Scroll




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	134-4647-S1	1	Scroll Assy (Includes Parts Marked *)
2	509-0297	1	*Seal, Air Intake
3	134-4635	1	*Housing, Scroll
4	134-4648	1	*Link, Preheat (Early Specs Only)
5	134-4649	1	*Door, Preheat (Early Specs Only)
6	823-0002-09	3	Screw, Pan Head Torx Threads Forming (M40 x .7 x 16mm)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	140-2105	1	Element, Air Filter
8	140-2144	1	Retainer, Element
9	140-2137	1	Cover, Element

* - Parts Included in Gasoline Units Scroll Assy.

Starter Components KV (Spec A-J) KVC (Spec A-B)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-1798	1	Starter (B1)
1	191-2156	1	Cap Assy, End (Includes Brushes)
2	191-2155	1	Armature
3	191-2156	1	Cap Assy, Drive (Includes Bushing)
4	191-2157	1	Kit, Drive (Includes Parts Marked *)
5	191-1821	1	*Retainer, Spring
6	191-1870	1	*Spring, Pinion

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	191-1869	1	*Pin, Spiral Roll
8	191-1863	1	*Cover, Spring
9	191-1864	1	*Retainer, Clutch
10	191-1865	1	*Washer
11	191-1868	1	*Gear, Starter
12	191-1866	1	*Clutch and Spline


* - Parts Included in Drive Kit.

Starter Components
KV (Begin Spec K) KVC (Begin Spec C)
KVD (Begin Spec A)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-2351	1	Starter, Complete (B1)	5	191-2316	1	Holder Assy, Brush (Includes Brushes)
1	191-2320	1	Retainer, Ring	6	191-2313	1	Kit, Drive (Includes Ring Retainer, Retainer Spacer, Wave Washer, Spring, Starter Gear, and Clutch/Spline)
2	191-2156	1	Cap Assy, Drive (Includes Bushing)				
3	191-2321	1	Armature				
4	191-2317	1	Cap Assy, End (Includes Bushing)				

Generator




Generator

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	815-0669	1	Bolt, Rotor Thru (3/8-16NC x 3.50")	11	232-3312	2	Cap, Terminal (Natural)
2	526-0392	1	Washer, Fan Hub	12	515-0289	1	Key, Fan Hub
3			Hub Assy, Fan (Includes Magnet & Rivets) KV	13			Rotor, Generator (Includes Bearing and Collector Ring) KV
	205-0174	1	Spec A-B (Includes Parts Marked @)		201-3606-01	1	60Hz Spec A-B
	205-0172	1	@ Fan		201-3606-02	1	Spec C-H
	134-4531	3	@ Insert		201-3606-03	1	Begin Spec J
	823-0003-03	3	@ Screw, Socket Drive Pan Head (M6 x 20mm)		201-3606-01	1	50Hz Spec A-B
	205-0206	1	Begin Spec C		201-3606-02	1	Spec C-E
	205-0206	1	KVC, KVD				Spec F-G 33742 & 51894
4	823-0003-04	10	Screw, Pan Head Trox Thread Forming (M6 x 1 x 25mm)		201-3606-03	1	Begin Spec F
5	740-1004	10	Washer, Flat (M6) (KV Begin Spec J, KVC Begin Spec B, KVD)		201-3606-03	1	KVC 60Hz Begin Spec A
6	509-0420	1	O'Ring (Supersedes 509-0196)		201-3606-03	1	KVD 60Hz and 50Hz Begin Spec A
7	510-0099	1	Bearing, Ball	14	307-2659	1	Solenoid, Throttle Closing (Includes Nut and Washer) (K4) (KV)
8	204-0139	1	Ring, Collector	15	740-1004	1	Washer, Flat (M6) (KV Spec A-H)
9			Stator, Generator KV	16	307-2655-02	1	Bracket, Solenoid (KV)
			60Hz	17			Housing, Stator KV
	220-4125-S1	1	Spec A-H				Spec A-H
	220-4125-07	1	Begin Spec J		220-4595-01	1	100V, 120V, 220V
			50Hz		220-4595-02	1	230V
	220-4125-03	1	Spec A-E		220-4595-02	1	Spec J-L KVC, Spec B KVD (64mm)
			Spec F-G 33742 & 51844				
	220-4125-04	1	Spec F-H	18	520-2037	6	Stud, Generator Mounting
	220-4125-08	1	Begin Spec J	19	870-0212	1	Nut, Hex Flange Locking (1/4-20) (KV Spec A)
			KVC	20	402-0547	1	Isolator, Vibration (KV Spec A)
			60Hz	21	166-0816-S0	1	Assy, Magnet
	220-4125-06	1	Spec A				
	220-4125-07	1	Begin Spec B				
			KVD				
			60Hz				
	220-4125-07	1	Spec A				
			50Hz				
	220-4125-08	1	Begin Spec B				
10	232-3311	2	Cap, Terminal (Black)				


@- Parts Included in Spec A-B Fan Hub Assy

Control (KV Spec A-F)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-9860-02	1	Box, Control Spec A,B	13	307-2594	1	Relay, Start Disconnect (K2)
	319-1347-02	1	Spec C-F	14			Capacitor (C1)
2	870-0235	1	Nut, Self Locking (8-32)		356-0138-02	1	Spec A, B
3	300-5299	1	PCB Assy (Includes PCB Harnesses, Switch Cover and Switch) (Spec C-F)		300-4329	1	Spec C-F
4	338-2743	1	Harness, PCB (P1)(Spec C-F) Obsolete	15	812-0066	1	Screw, Round Head Machine (#6-32 x 3/4")
5	338-2742	1	Harness, PCB (P2)(Spec C-F) Obsolete	16	356-0070	1	Clamp
6	308-0995	1	Switch, Rocker (Spec C-F)	17	860-0006	1	Nut, Hex (#6-32)
7	308-0996	1	Cover, Rocker Switch (Spec C-F)	18	823-1002-01	2	Screw, Pan Head Machine (M6 x 1 x 12mm)
8	870-0488	4	Standoff, PCB (Spec C-F)	19			Relay, Stop (12V)
9	870-0487	4	Rivet, Standoff (Spec C-F)		307-1886	1	K5
10			Breaker, Circuit (CB1)		307-1886	1	K6 (Used on 1.7 And 2.0 KV) (3 Wire)
	320-1318	1	7.5A		307-2562	1	K3 Magneto Grounding
	320-1663-01	1	9.5A	20	812-0079	1	Screw, Round Head Machine (#8-32 x 1/2")
	320-1320	1	15A	21	526-0003	1	Washer, Flat
	320-1319	1	10A	22	321-0298	2	Fuse (F1, F2)
	320-1713-01	1	2.3KV-FR/51844F	23	321-0305	2	Holder, Fuse (Cap and Base)
			2KV-FR/37544A	24	308-0768	1	Switch, Rocker (S1)
	320-1663-02	1	2.0KV-FR/26119F	25	815-0549	2	Screw, Cross Recessed ET Phillips (#6-32 x 1/4")
			2.4KV-FR/33742F	26	517-0135	1	Plug, Hole
	320-1322	1	25A	27	319-1675-02	1	Plate, Circuit Breaker (Used with 320-1713-01 Spec 51844 Spec A-F)
11	332-1571	1	Terminal, Tab Adapter (Used on 2.8 KV)	28	302-2031	1	Transformer Assy (100V Sets)
12	823-0001-01	4	Screw, Socket Drive Pan Head (M3 x 6MM)				


Control (KVD and KV Begin Spec G)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-1347-02	1	Box, Control
2	300-5299	1	PCB Assy (Includes PCB Harnesses, Switch Cover Label and Switch)
3	338-2742	1	Harness, PCB (P2) Obsolete
4	338-2743	1	Harness, PCB (P1)
5	308-0995	1	Switch, Rocker (S1)
6	308-0996	1	Cover, Rocker Switch
7	870-0488	4	Standoff, PCB
8	870-0487	4	Rivet, Standoff
9			Breaker, Circuit
	320-1663-02	1	10 Amps
			2.3KVFR33742
			2KVFR26119
	320-1713-01	1	10 Amps
			2.3KVFR51844
	320-1322	1	25 Amps
			2.8KV
			FA26100,FR11351
			FA11574
			2.5KVFR11540

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
10	815-0549	2	Screw, Cross Recessed ET Phillips (#6-32 x 1/4")
11	319-1675-02	1	Plate, Circuit Breaker (Used with 320-1713-01)
12	302-2031	1	Transformer Assy (100V Sets)
13	823-1002-01	2	Screw, Pan Head Torx (M6 x 1 x 12mm)


Control KVC



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	166-0784-S0	1	Coil Assy, Ignition (Includes Lead, Boot and Terminal)	13	338-2742	1	Harness, PCB (P2) Obsolete
2	167-0265	1	Boot, Spark Plug	14	300-5299	1	PCB, Control (Includes PCB Harnesses, Switch Cover and Switch)
3	167-0267	1	Terminal, Spark Plug	15	308-0995	1	Switch, Rocker
4	166-0779	1	Coil, Ignition	16	308-0996	1	Cover, Rocker Switch
5	823-0002-04	4	Screw, Pan Head Torx Thread Form (M4 x 0.7 x 12mm)	17	331-0564	1	*Conduit Assy (Includes Connectors and Conduit)
6	308-0949	1	Cover, Switch	18	331-0563	1	*Connector, 45°
7	302-2002	1	Meter, Hour	19	331-0565	1	*Conduit, Flex (1/2")
8	302-2031	1	Transformer Assy (100V Units) (Reaches from Control PCB to Genset [J2] Harness)	20	331-0007	1	*Connector, Straight Conduit (1/2") Obsolete
9	320-1322	1	Breaker, Circuit (25A)	21	331-0533	2	Bushing, Anti Short (1/2")
10	815-0549	2	Screw, Pan Head Cross Recessed (#6-32 x 1/4")	22	338-3844	1	Harness, AC Output
11	870-0487	4	Rivet, Standoff				
12	338-2743	1	Harness, PCB (P1)				


* - Marked Items For Reference only Not For Sale

Remote Panel (KV Spec A-E)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Screw, Oval Head Cross Recessed Wood (#5 x 1/2")	4	302-0885	1	Meter, Hour (M2)
	815-0380	2	Standard Control	5	302-0888	1	Meter, Battery Condition (M1)
	815-0380	4	Deluxe Control	6	359-0034	1	Diode Obsolete
2	308-0341	1	Switch, Rocker (S1)	7	815-0385	2	Screw, Round Head Machine (#6-32 x 1/2")
3			Panel, Control	8	860-0006	2	Nut, Hex Head (#6-32)
	301-3566	1	Standard Control				
	301-3606	1	Deluxe Control (Obsolete)				


Remote Switch Panel (KV Begin Spec F)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	300-4936	1	Kit, Remote Switch Panel
1	815-0910	2	Screw, Wood (#6 x 1")
2	319-2339-01	1	Panel, Printed
3	308-1062	1	Switch, Rocker

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
4	338-3510	1	Harness, Remote Panel (Includes Plug and Pins)
5	323-1304	1	Plug, 6-Pin
6	323-1199	4	Pin, Contact


Remote Switch/Hourmeter Panel (KVD and KV Begin Spec F)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	300-4937	1	Kit, Remote Switch/Hourmeter Panel
1	815-0910	2	Screw, Wood (#6 x 1")
2	319-2340-03	1	Panel, Printed
3	308-1062	1	Switch, Rocker

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
4	302-2002	1	Hourmeter
5	338-3466	1	Harness, Remote Panel (Includes Plug and Pins)
6	323-1304	1	Plug, 6-Pin
7	323-1199	4	Pin, Contact


Remote Switch/Voltmeter Panel (KVD and KV Begin Spec F)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	300-4938	1	Kit, Remote Switch/Voltmeter Panel
1	815-0910	2	Screw, Wood (#6 x 1")
2	319-3132-02	1	Panel, Printed
3	308-1062	1	Switch, Rocker
4	302-1641	1	Voltmeter
5	526-0409	2	Washer, Nylon Flat (#10)
6	526-0049	4	Washer, Brass Flat (#10)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	850-0030	2	Washer, Lock (#10)
8	871-0010	4	Nut, Hex Brass Machine (#10-32)
9	338-3507	1	Harness, Remote Panel (Includes Plug and Pins)
10	323-1304	1	Plug, 6-Pin
11	323-1199	4	Pin, Contact

Remote Wiring Harness (KV Spec A-E)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338-1082	1	Harness, 6" Wiring (Includes Parts Marked *)
2	323-0500	5	*Pin, Contact
3	332-0942	1	+*Tie, Cable
4	323-0400	1	*Housing, Connector (6 Place)
5	338-2046	1	Harness, 6" Wiring (Includes Parts Marked +)
6	323-1304	1	+Housing, Connector (6 Place)
7	323-1199	5	+Pin, Contact
8	338-2137	1	Harness, 6" Wiring (Includes Parts Marked ~)
9	323-1304	1	~Housing, Connector (6 Place)
10	323-1199	5	~Pin, Contact
11	323-0488	5	~Socket, Connector

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
12	323-0440	1	~Housing, Connector (6 Place)
13			Harness, Wiring (Includes Parts Marked &)
	338-2260-01	1	Ten Foot
	338-2260-02	1	Thirty Foot
14	323-1199	5	&Pin, Contact
15	323-1304	1	&Housing, Connector (6 Place) (J2)


* - Parts Included in 338-1082 Wiring Harness.

+ - Parts Included in 338-2046 Wiring Harness.

~ - Parts Included in 338-2137 Wiring Harness.

& - Parts Included in 338-2260-01 & -02 Wiring Harness.


Generator Harness (KV Spec A, B)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Harness, Generator Gasoline Sets (Includes Parts Marked *)	7	307-1886	1	++Relay (LP=K3) (Gasoline=K5)
	338-2441-01	1	Spec 29236	8	323-1342	1	++Housing, Terminal (P2) (6 Pin)
	338-2441-02	1	Spec 33742, 37544A	9	307-1575	1	*Relay (Gasoline=K3)
	338-2615-02	1	Spec 37544B	10			Harness, Wiring Z1 (DC)
	338-2210	1	Spec 26100		338-2209	1	* Gasoline Units
2			LP Sets (Includes Parts Marked +)		338-2614	1	+ LP Units Z2 (DC)Obsolete
	338-2731	1	Spec 26119		338-2208	1	* Gasoline Units
	338-2591	1	Spec 26120		338-2613	1	+ LP Units Obsolete
3	357-0030	2	++Rectifier, Silicon (CR1, CR2)		338-2618	1	* Z3 (Spec 37544B Only) Z4
4	323-1443	1	++Socket, Relay (8 Pin) (K2) Obsolete		338-2440	1	++ Spec 29236, 33742, 37544A, 26119 Obsolete
5	323-1314	1	++Plug, Connector (12 Pin) (P1)		338-2617	1	* Spec 37544B
6			*Resistor, Fixed (P1-4 to P1-5) (Includes Slewing & Sockets)				
	304-0805-01	1	Spec 29236				
	304-0805-02	1	Spec 33742, 37544				

* - Parts Included in Gasoline Generator Harness.
+ - Parts Included in LP Generator Harness.

Generator Harness (KV Spec C-E)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Harness, Generator	7			+ Harness, DC
	338-2741	1	J1 (Includes Parts Marked *) Spec 11351, 26100, 26119, 26120, 33742, 2089A		338-2740	1	Z1 Z4
	338-2771	1	Spec 51844 J2 (Includes Parts Marked +)		338-2763	1	Spec 26119, 33742
	338-2739	1	Spec 26100, 26120		338-2773	1	Spec 51844
	338-3263	1	Spec 11351	8	304-0821	1	+ Resistor (R1)
	338-2762	1	Spec 26119, 33742	9	305-0718	1	+ Rectifier, Bridge (CR1)
	338-2772	1	Spec 51844	10	323-1547	1	+ Wedge, Receptacle (J2)(4 Pin)
1	323-1342	1	*Housing, Terminal (6 Pin) (J5)	11	323-1549	1	+ Socket, Receptacle (J2)
2	321-0312-S1	1	*Fuse Assy, 5A (F1) (Includes Fuse)	12			+ Resistor, Fixed (P3-1 P3-5) (Includes Slewing & Sockets)
3	321-0307-03	1	*Fuse, 5A (F1)		304-0805-02	1	Spec 51844 (J4-4 to J4-5) Spec 26199, 33742 (P3-4 to P3-5)
4	323-1542	1	*Receptacle (8 Pin) (J1)		304-0805-04	1	Spec 11351 (P3-1, P3-5)
5	323-1544	1	*Wedge, Receptacle (8 Pin) (J1)				
6	323-1314	1	*Plug, Connector (12 Pin) (P3)				

* - Parts Included in (J1) Generator Harness.

+ - Parts Included in (J2) Generator Harness.


Generator Harness (KV Begin Spec F)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Harness, Generator	5	323-1544	1	*Wedge, Receptacle (8 Pin) (J1)
			J1 (Includes Parts Marked *)	6	323-1708	4	*Seal, Cable (J5)
388-3628		1	Spec 11351, 11540,	7	323-1741	1	*Housing, Lock (J5)
			26100, 26119, 26120,	8	323-1712	6	*Plug, Cavity (J5)
			33742	9	304-0805-05	1	+Resistor (R1)
338-3528		1	Spec 51844 Obsolete				Spec 11351, 11540
338-3672		1	Spec 11574 Obsolete				(P3-1, P3-5)
			J2 (Includes Parts Marked +)				Spec 51844, 26119, 33742
			Spec 51844				(P3-4, P3-5)
338-3607		1	Spec 11351, 11540	10	323-1547	1	+Wedge, Receptacle (4 Pin) (J2)
338-3549		1	Spec 26119, 33742	11	323-1549	1	+Socket, Receptacle (J2)
338-3574		1	Spec 11574, 26100,	12	323-1314	1	+Plug, Connector (12 Pin) (P3)
338-3550		1	26120	13			+Harness, DC
			Begin Spec L		338-2740	1	Z1
1	323-1743	1	*Connector, Plug (8 Pin) (J5)		338-2773	1	Z4 (Spec 51844 Only)
2	321-0312-S1	1	*Fuse Assy, 5A (F1) (Includes Fuse)				
3	321-0307-03	1	*Fuse, 5A (F1)				
4	323-1542	1	*Receptacle (8 Pin) (J1)				

* - Parts Included in (J1) Generator Harness.
+ - Parts Included in (J2) Generator Harness.

Generator Harness KVC



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	338-3842	1	Harness, Generator J1 (Includes Parts Marked +) J2 (Includes Parts Marked *)
	338-3843	1	120V Units
	338-3846	1	100V Units
1	323-1314	1	*Plug, Connector (P3) (12 Pin)
2	323-1549	1	*Socket, Receptacle (J2)
3	323-1547	1	*Wedge, Receptacle (J2) (4 Pin)
4	323-1542	1	+Receptacle (J1) (8 Pin)
5	323-1544	1	+Wedge, Receptacle (J1) (8 Pin)
6	323-1491	8	+Terminal, Pin (J1)
7	321-0325	1	+Holder, Fuse (F1)
8	321-0307-03	1	+Fuse (5A) (F1)


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
9	323-1743	1	+Connector, Plug (J5) (Pin)
10	323-1709	4	+Terminal, Socket (J5)
11	323-1741	1	+Housing, Lock (J5)
12	323-1712	4	+Plug, Cavity (J5)
13	323-1708	4	+Seal, Cable (J5)
14	508-0095	1	+Grommet

+ - Parts Included in (J1) Genset Harness.

* - Parts Included in (J2) Genset Harness.

* - Parts Included in 338-2428 Wiring Harness


Generator Harness KVD



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1		1	Harness, Generator (Included with Harness*)
	338-4070	1	Spec A
	338-4381	1	Begin Spec B
2	323-1549	1	*Socket, Receptacle
3	323-1547	1	*Wedge, Receptacle (4 Pin)
4	323-1314	1	*Plug, Connector (12 Pin)
5	323-1491	AR	*Terminal, Pin
6	332-2571	AR	*Terminal, Receptacle (25 x 90)
7			Harness, Generator
	338-3628	1	Spec A
	338-4320	1	3729A and Begin Spec B


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
8	321-0312-S1	1	+ Fuse Assy, (5Amp)(F1)
9	323-1542	1	+ Receptacle (8 Pin)
10	323-1544	1	+ Wedge, Receptacle (8 Pin)
11	323-1743	1	+ Connector, Plug (8 Pin)(J5)
12	323-1741	1	+ Housing, Lock
13	323-1712	1	+ Plug, Cavity
14	323-1709	1	+ Terminal, Socket

PCB Harness



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338-2428	1	Harness, PCB (Includes Parts Marked *) (KVC, KVD and KV, Spec 51844)	3	332-2659	2	*Terminal, PCB Tab
2	323-1315	1	*Cap, Connector (12 PI)	4	323-1199	2	*Pin, Contact
				5	338-3850	1	Harness, Wiring (Z1) (Includes Parts Marked #) (KVC)

**Remote Wiring Harness
(KVC, KVD and KV Begin Spec F)**



Remote Wiring Harness (KVC, KVD and KV Begin Spec F)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338-3572	1	Harness, Adapter (Pigtail at Control Panel) (Includes Parts Marked *) (Use With Gasoline and LP Kits 300-4936, 300-4937, & 300-4938)	17	323-1741	1	<@ Lock, Housing (8 Pin)
				18	323-1744	1	<@ Connector, Receptacle (8 Pin)
2	323-1342	1	*Housing, Terminal	19	323-1707	5	@ Pin, Terminal
3	323-1200	5	*Socket, Contact	20	323-1712	3	<@ Plug, Cavity
4	305-0979	1	Kit, Remote Adapter (Pigtail at Genset End) (Includes Parts Marked ^)	21	323-1708	5	<@ Seal, Cable
		1	^Seal, Cable	22	323-1342	1	<@ Housing, Terminal
5	323-1708	2	^Splice, Thermal (Not Shown)	23	323-1200	5	<@ Socket, Contact
6	332-3582	5	^Sheet, Instruction (Not Shown)	24	338-3514	1	Harness, Adaptor (6 Inches) (For Sets Prior to Spec F) (Include Parts Marked ~)
7	C-571	1	^Harness, Remote (Includes Parts Marked #)	25	323-1199	5	~ Pin, Contact
8	300-4946	1	#Lock, Housing (8 Pin)	26	323-1304	1	~ Housing, Connector (6 Place)
9	323-1741	1	#Connector, Receptacle (8 Pin)	27	323-1743	1	~ Connector, Plug (8 Pin)
10	323-1744	5	#Pin, Terminal	28	323-1741	1	~ Lock, Housing (8 Pin)
11	323-1707	3	#Plug, Cavity	29	323-1712	3	~ Plug, Cavity
12	323-1712	5	#Seal, Cable	30	323-1708	5	~ Seal, Cable
13	323-1708	1	Kit, Remote Adapter (Lead Assemblies)	31	323-1709	5	~ Socket, Terminal
14	0305-0980	1	Harness, Adaptor (6 Inches) (New Set to Old Panel) (Includes Parts Marked @)				
15	338-3513	1	Harness, Remote (Includes Parts Marked <)				
16							
	338-3489-01	1	10 Feet				
	338-3489-02	1	30 Feet				

* - Parts Included in 338-3572 Adapter Harness.
^ - Parts Included in 305-0979 Remote Adapter Kit.
- Parts Included in 300-4946 Remote Harness.
@ - Parts Included in 338-3513 Adapter Harness.
< - Parts Included in 338-3489-01 & -02 Remote Harness.
~ - Parts Included in 338-3514 Adapter Harness.

Labels and Paint

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
98-5759	1		Label, Warning (Hazardous Voltage) (KV, KVD)	98-7494-01	1		KVD Label, Listed (White, KVD 2.5 and 2.8)
98-5797	1		Label, Air Filter (Gasoline)	98-7997-01	1		Label, Logo (2500)
98-5820	1		Label, Rating (Amp) (KV)	98-7997-02	1		Label, Logo (2800)
98-5926	1		Label, Warning (Noxious Fumes) (KV)	98-7997-03	1		Label, Logo (2000)
			Label, Barcode (KVC and KVD)	98-7997-04	1		Label, Logo (2300)
			Label, Amp Rating (KV)	98-6388-02	1		Label, Phone Info
98-5976-03	1		25A (KVD 2.0 and 2.3)	98-8052	1		Label, Warning (Substances)
98-5976-04	1		9.5A	98-5757	1		Label, Warning (Hazardous Voltage)
98-5976-06	1		10A (Begin Spec F and KVD 2.0 and 2.3)	98-7494-01	1		Label, Listed (KVD)
98-5976-03	1		Label, Amp Rating (25 Amp) (KVD)	98-7628	1		Label, Warning (Install)(KVC)
			*Label, Warning (Substances)	98-7639	1		Label, Warning (Install, Hazardous Volt/Exhaust Gasoline)(KVC)
98-6074-02	1		Label, Air Filter (All Units)	98-7921	1		Label, Warning (Install)(KVD)
98-6308	1		Label, AC Notice (2.8) (KV)	98-7927	1		Label, Warning (Install)(KVD)
98-6313	1		(Gasoline)	98-7939-02	1		Label, Blank (KVC and KVD)
98-6388-02	1		Label, Phone Info	525-0305	AR		Paint, Green Enamel (13 oz. Pressurized Spray Can)
98-6448	1		Label, Control (KVD)	518-0452	AR		Sealant, Thread (50 cc Bottle)
98-6476	1		*Label, Ground (All Units)	98-6569-06	1		LP
98-6476	2		*Label, Ground (KVD)	98-6569-07	1		Gasoline
			KV				
			Gasoline				
98-6569-01	1		2000				
98-6569-04	1		2800				
98-6569-05	1		2300				
98-6569-05	1		2800				
			KV				
			LP				
98-6569-02	1		2000				
98-6569-03	1		2500				

* - Parts Sold in Kit Only

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
098-5757, 68		134-4647-S1, 46		149-2120, 23		153-0692-02, 14	
098-5759, 68		134-4648, 46		149-2137, 15		153-0693, 14	
098-5797, 68		134-4649, 46		149-2140, 23		154-2746, 32	
098-5820, 68		140-2105, 46		149-2300, 23		155-1239, 33	
098-5926, 68		140-2137, 46		149-2327, 23		155-1256, 31, 32, 33	
098-5976-03, 68		140-2144, 46		149-2331-03, 27		155-2174, 33	
098-5976-04, 68		140-2978, 16, 19, 21		149-2524-01, 25		155-2233-02, 29	
098-5976-06, 68		140-2979, 16, 19, 21		149-2588, 23		155-2301-02, 29	
098-6074-02, 68		140-2980, 16, 19, 21		149-2615, 23		155-2322, 33	
098-6308, 68		140-2981, 16, 19, 21		149-2633, 15, 16		155-2323, 33	
098-6313, 68		140-3499-02, 21		149-2636, 15		155-2324, 33	
098-6388-02, 68		145-0589, 16, 19, 21		150-2286, 11		155-2325, 33	
098-6448, 68		146-0540, 16, 17		150-2302, 8		155-2425, 33	
098-6476, 68		146-0545, 19		150-2305, 8		155-2449, 28	
098-6569-01, 68		146-0569, 16		150-2394, 11		155-2665, 33	
098-6569-02, 68		146-0570, 19		150-2395, 11		155-2771, 33	
098-6569-03, 68		146-0573, 19		150-2396, 11		155-2772, 33	
098-6569-04, 68		146-0574, 19		150-2448, 11		155-2953, 29, 30, 31, 32	
098-6569-05, 68		146-0575, 19		150-2449-02, 11		155-3312, 31	
098-6569-06, 68		146-0576, 19		150-2450-02, 11		155-3313, 31	
098-6569-07, 68		146-0667, 19		150-2514, 11		155-3314, 31	
098-7494-01, 68		146-0705, 16		151-0700, 11		155-3315, 31	
098-7628, 68		146-0721, 19		153-0554, 12		155-3342-02, 31	
098-7639, 68		146-0753, 19		153-0595, 12		155-3435-01, 30	
098-7921, 68		146-0760, 19		153-0596, 12		155-3435-02, 30	
098-7927, 68		146-0770, 19		153-0598, 12		155-3436-01, 29, 30	
098-7939-02, 68		146-0801, 19		153-0599, 12		155-3436-02, 29, 30	
098-7997-01, 68		146-0802, 16		153-0600, 12		155-3539, 32	
098-7997-02, 68		146-0830, 21		153-0602, 12		155-3541, 39	
098-7997-03, 68		146-0840, 19, 21		153-0604, 12		155-3557-02, 32	
098-7997-04, 68		146-0841, 21		153-0605-02, 12		155-3562, 32	
098-8052, 68		148-0932-02, 19		153-0609, 12		160-1358-S0, 45	
100-3389, 6		148-0963, 19		153-0610, 12		166-0779, 54	
102-1367, 10		148-1012, 19		153-0611, 12		166-0784-S0, 34, 35, 54	
123-2044, 9		148-1124-02, 19		153-0640, 13, 14		166-0816-S0, 51	
123-2129, 9, 21		148-1125, 19		153-0645, 13		167-0263-02, 9	
134-4531, 51		148-1260, 21		153-0647-02, 13		167-0265, 34, 35, 54	
134-4635, 46		148-1261-02, 21		153-0651-02, 13, 14		167-0267, 34, 35, 54	
134-4636-01, 9		148-1267-02, 21		153-0659, 13, 14		167-1636, 23, 25	
134-4637, 45		148-1284, 21		153-0691-02, 14		185-2366, 11	

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
185-2731, 8		185-5099, 6		185-5150, 11		185-5203, 6	
185-2914, 8		185-5100, 8		185-5151, 11		185-5204, 6	
185-3077, 10		185-5101, 8		185-5152, 11		185-5205, 6	
185-3078, 10		185-5102, 8		185-5156, 9		185-5313, 6	
185-3085, 7		185-5103, 8		185-5157, 9		185-5314, 17	
185-3088, 7		185-5104, 8		185-5158, 9		185-6373, 8	
185-3175, 6		185-5105, 8		185-5159, 9		185-6374, 8	
185-3245, 17		185-5106, 8		185-5160, 9		185-6375, 8	
185-3365, 7		185-5107, 8		185-5163, 17		185-6677, 11	
185-3366, 7		185-5108, 8		185-5164, 17		185-6955, 11	
185-3367, 7		185-5109, 7		185-5165, 17		185-6957, 11	
185-3368, 7		185-5110, 7		185-5166, 17		185-7090, 11	
185-3369, 7		185-5111, 7		185-5167, 17		185-7091, 7	
185-3370, 7		185-5112, 7		185-5168, 17		185-7221, 11	
185-3371, 7		185-5113, 7		185-5169, 17		191-1798, 45, 47	
185-3389, 8		185-5114, 7		185-5170, 17		191-1821, 47	
185-3392, 8		185-5115, 7		185-5172, 17		191-1825-02, 45	
185-3393, 8		185-5116, 7		185-5173, 17		191-1863, 47	
185-3394, 8		185-5117, 7		185-5174, 17		191-1864, 47	
185-3395, 8		185-5118, 7		185-5175, 17		191-1865, 47	
185-3396, 8		185-5119, 10		185-5176, 17		191-1866, 47	
185-3397, 8		185-5120, 10		185-5177, 17		191-1868, 47	
185-3398, 8		185-5121, 10		185-5178, 17		191-1869, 47	
185-3399, 8		185-5122, 10		185-5179, 17		191-1870, 47	
185-3416, 7		185-5123, 10		185-5180, 17		191-2155, 47	
150-2275, 8		185-5124, 10		185-5181, 17		191-2156, 47, 49	
185-3674, 8		185-5125, 10		185-5182, 17		191-2157, 47	
185-3675, 8		185-5126, 10		185-5183, 17		191-2312, 45	
185-3730, 6, 9		185-5127, 16, 19		185-5184, 17		191-2313, 49	
185-3761, 7		185-5128, 16		185-5185, 17		191-2316, 49	
185-4498, 11		185-5129, 16, 19, 21		185-5186, 17		191-2317, 49	
185-4499, 11		185-5134, 16, 19		185-5193, 6		191-2320, 49	
185-4547, 7		185-5135, 16, 21		185-5194, 6		191-2321, 49	
185-4551, 8		185-5136, 16		185-5195, 6		191-2351, 45, 49	
185-4558, 17		185-5137, 16, 21		185-5196, 6		201-3606-01, 51	
185-4563, 17		185-5138, 16, 21		185-5198, 6		201-3606-02, 51	
185-5095, 6		185-5139, 16		185-5199, 6		201-3606-03, 51	
185-5096, 6		185-5145, 11		185-5200, 6		204-0139, 51	
185-5097, 6		185-5148, 11		185-5201, 6		205-0172, 51	
185-5098, 29, 30, 31, 32		185-5149, 11		185-5202, 6		205-0174, 51	

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
205-0206, 51		304-0805-04, 61		321-0312-S1, 61, 62, 64		332-2634, 6, 29	
211-0408, 45		304-0805-05, 62		321-0325, 63		332-2659, 65	
211-0450, 45		304-0821, 61		323-0400, 59		332-2897, 23, 25, 27	
211-0486, 45		305-0718, 61		323-0440, 59		332-2900, 23	
211-0527, 45		305-0767-02, 34		323-0488, 59		332-3582, 67	
212-1276-03, 45		305-0830-02, 34		323-0500, 59		337-0049, 29, 37, 38, 39	
212-1285, 45		305-0852, 34		323-1199, 56, 57, 58, 59, 65, 67		338-1082, 59	
214-0103, 45		305-0897, 27, 34, 35		323-1200, 67		338-2046, 59	
220-4125-03, 51		305-0979, 67		323-1304, 56, 57, 58, 59, 67		338-2137, 59	
220-4125-04, 51		307-1575, 60		323-1314, 60, 61, 62, 63, 64		338-2208, 60	
220-4125-06, 51		307-1886, 52, 60		323-1315, 65		338-2209, 60	
220-4125-07, 51		307-2562, 52		323-1342, 60, 61, 67		338-2210, 60	
220-4125-08, 51		307-2570, 27		323-1443, 60		338-2260-01, 59	
220-4125-S1, 51		307-2586, 23, 25		323-1491, 63, 64		338-2260-02, 59	
220-4144-02, 51		307-2594, 52		323-1507, 23, 25		338-2428, 65	
220-4595-01, 51		307-2655-02, 51		323-1542, 61, 62, 63, 64		338-2440, 60	
220-4595-02, 51		307-2659, 51		323-1544, 61, 62, 63		338-2441-01, 60	
232-3278, 45		307-2961, 25		323-1544, 64		338-2441-02, 60	
232-3311, 51		308-0341, 55		323-1547, 61, 62, 63, 64		338-2591, 60	
232-3312, 51		308-0768, 52		323-1549, 61, 62, 63, 64		338-2613, 60	
232-3720, 13, 14		308-0949, 54		323-1707, 67		338-2614, 60	
232-4008, 45		308-0995, 52, 53, 54		323-1708, 62, 63, 67		338-2615-02, 60	
300-4329, 23, 25, 27, 52		308-0996, 52, 53, 54		323-1709, 63, 64, 67		338-2617, 60	
300-4936, 56		308-1059, 6		323-1712, 62, 63, 64, 67		338-2618, 60	
300-4937, 57		308-1062, 56, 57, 58		323-1741, 62, 63, 64, 67		338-2731, 60	
300-4938, 58		319-1347-02, 52, 53		323-1743, 62, 63, 64, 67		338-2739, 61	
300-4946, 67		319-1675-02, 52, 53		323-1744, 67		338-2740, 61, 62	
300-5299, 52, 53, 54		319-2339-01, 56		331-0007, 54		338-2741, 61	
301-3566, 55		319-2340-03, 57		331-0521, 23, 25		338-2742, 52, 53, 54	
301-3606, 55		319-3132-02, 58		331-0533, 54		338-2743, 52, 53, 54	
301-9860-02, 52		320-1318, 52		331-0563, 54		338-2762, 61	
302-0885, 55		320-1319, 52		331-0564, 54		338-2763, 61	
302-0888, 55		320-1320, 52		331-0565, 54		338-2771, 61	
302-1641, 58		320-1322, 52, 53, 54		332-0942, 59		338-2772, 61	
302-2002, 54, 57		320-1663-01, 52		332-1356, 19		338-2773, 61, 62	
302-2031, 52, 53, 54		320-1663-02, 52, 53		332-1420, 23, 25		338-3263, 61	
304-0796, 45		320-1713-01, 52, 53		332-1571, 52		338-3466, 57	
304-0797, 45		321-0298, 52		332-2571, 64		338-3489-01, 67	
304-0805-01, 60		321-0305, 52				338-3489-02, 67	
304-0805-02, 60, 61		321-0307-03, 61, 62, 63				338-3507, 58	

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
338-3510, 56		405-3816, 38		502-0397, 28		509-0297, 46	
338-3513, 67		405-4321-02, 23		502-0398, 28		509-0420, 51	
338-3514, 67		405-4323-02, 34		502-1133, 25		510-0099, 51	
338-3528, 62		405-4326, 40		502-1140, 25		515-0289, 51	
338-3549, 62		405-4328, 40		502-1162, 25		517-0135, 52	
338-3550, 62		405-4417-02, 23		502-1300, 19		517-0254, 34, 35	
338-3572, 67		405-4423-02, 34		503-0446, 21		517-0305, 13, 14	
338-3574, 62		405-5812, 23, 25		503-0731, 15, 19, 21, 28		518-0129, 12	
338-3607, 62		405-5827-02, 23		503-1133, 19, 25		518-0371, 12	
338-3628, 64		405-5828-02, 25		503-1199, 19, 28		518-0450, 12	
338-3672, 62		405-6444-02, 36		503-1338, 12		518-0452, 68	
338-3842, 63		405-6446-02, 26		503-1418, 15, 21		518-0532, 12	
338-3843, 63		405-6447-02, 36		503-1445-06, 9, 21		518-0533, 9	
338-3844, 54		405-6448-01, 26		503-1777, 15		518-0576, 11	
338-3846, 63		405-6448-02, 26		503-1824, 15		518-0728, 34, 35	
338-3850, 65		405-6450, 26		503-1851, 19		520-1018-02, 27	
338-4070, 64		405-6451, 26		503-2004, 19, 25		520-2037, 51	
338-4320, 62, 64		405-6454, 26		503-2008, 19		520-2210, 36, 38, 39	
338-4381, 64		405-6481-02, 26		503-2143-02, 25		525-0305, 68	
356-0070, 23, 25, 27, 52		405-6485, 36		503-2143-05, 19		526-0003, 11, 13, 14, 45, 52	
356-0138-02, 52		405-6486, 26		503-2143-08, 21		526-0008, 12	
357-0030, 60		405-6487, 26		503-2146, 15		526-0029, 32	
359-0034, 55		405-6489, 36		503-2300, 15		526-0049, 58	
370-0116-02, 31		405-6490-01, 26		503-2309, 25		526-0077, 43	
388-3628, 62		405-6490-02, 26		504-0169, 28		526-0115, 27	
402-0547, 36, 38, 39, 51		405-6490-03, 26		505-0007, 28		526-0174, 43	
402-0601-01, 36, 38, 39		405-6494, 36		505-2119, 45		526-0392, 51	
402-0601-02, 36, 38, 39		405-6507, 36		508-0008, 36		526-0409, 58	
403-2679-02, 43		405-6509, 26		508-0068, 31		526-0432, 37	
403-2680-02, 43		405-6510, 36		508-0095, 63		526-2077, 8	
403-2689, 43		405-6938-02, 35		508-0179, 23, 25		526-2078, 8	
403-4417-02, 6		405-6956, 41		508-0258, 36		526-2100, 31	
403-4668-02, 43		405-6973-03, 25		508-0289, 23		541-0558, 15	
405-3784, 40, 41		405-6973-04, 23		508-0293, 23, 25		541-0618, 32	
405-3785, 23		405-6982, 39		508-0332, 27		541-0661, 43	
405-3789, 40		406-0612, 40, 41		508-1047, 43		541-0808, 19	
405-3790-S0, 40, 41		415-0511, 28		508-1116, 36		718-1036, 31	
405-3794, 34		502-0002, 23		508-1122, 25, 36		740-1004, 16, 19, 21, 38, 51	
405-3796, 38		502-0313, 23, 27		508-1168, 23		740-1006, 45	
405-3797, 34		502-0395, 28		508-1174, 23			

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
750-1004, 38		823-1002-01, 34, 35, 52, 53					
750-1006, 31, 45		850-0020, 13, 14					
800-0048, 43		850-0030, 21, 58					
800-0050, 43		850-0040, 39, 45					
800-2034, 31		850-0045, 23, 25, 27					
808-0008, 13, 14		853-0013, 45					
812-0066, 23, 25, 27, 52		853-0016, 27					
812-0079, 52		856-0002, 34, 35					
812-0087, 11		856-0006, 23, 27, 34, 35, 38, 39					
813-0103, 21		856-0008, 29, 37, 38, 39					
815-0261, 11, 19, 21		860-0006, 23, 25, 27, 52, 55					
815-0380, 55		860-2005, 13, 14, 27, 34, 35					
815-0385, 55		862-0001, 39, 45					
815-0508, 6, 30, 32, 38, 39		864-0002, 27					
815-0549, 52, 53, 54		868-0002, 23, 25, 27					
815-0660, 45		870-0212, 32, 38, 39, 51					
815-0669, 51		870-0235, 52					
815-0675, 40		870-0236, 45					
815-0685, 40, 41		870-0281, 43					
815-0709-01, 6, 29, 37		870-0487, 52, 53, 54					
815-0781, 45		870-0488, 52, 53					
815-0888, 45		870-2054, 23, 25, 29, 30, 31, 32, 34, 35, 36, 38, 39					
815-0910, 56, 57, 58		870-2055, 29					
821-0004, 19		870-2156, 36, 38, 39					
821-0010, 21, 27		871-0010, 58					
821-0016, 32		880-0528, 19					
821-2033, 38, 39		880-0538, 31					
821-2045, 29		880-0539, 31					
821-6002-02, 26, 36		895-0305-01, 40					
823-0001-01, 23, 25, 52		895-0305-02, 40					
823-0002-04, 12, 27, 54		895-0305-04, 34, 35					
823-0002-06, 35		898-1196-25, 15					
823-0002-09, 45, 46		898-1196-26, 15					
823-0003-03, 45, 51		898-1196-27, 15					
823-0003-04, 21, 51							
823-0003-05, 12, 19, 27							
823-0003-06, 9							
823-0006-01, 12							
823-1001-04, 34							



Cummins Power Generation
1400 73rd Avenue N.E.
Minneapolis, MN 55432
763-574-5000
Fax: 763-574-8087

Cummins and Onan are registered trademarks of Cummins Inc.